




User Manual Precision Scales

9434, 9435 and 9436

Requests & Notices

Model 9434, 9435 and 9436



Requests

- ▶ Provide this manual to the next user in the event that the instrument is transferred.
- ▶ To ensure safe operation, contact your Soehnle Professional scale representative for installation, adjustment, or reinstallation after moving the instrument to a different site.

Notices

- ▶ The content of this manual is subject, without notice, to modifications for the sake of improvement.
- ▶ Every effort has been made to ensure that the content of this manual was correct at the time of creation. However, in the event that any mistakes or omissions are discovered, it may not be possible to correct them immediately.
- ▶ The copyright of this manual is owned by Soehnle Industrial Solutions GmbH. Reproduction and duplication of whole or part of the content without permission of the company are strictly prohibited.
© 2016 Soehnle Industrial Solutions GmbH. All rights reserved.
- ▶ "Microsoft", "Windows", "Windows Vista" and "Excel" are registered trademarks of Microsoft Corporation of the U.S.A. in the United States and other countries. All other company names and product names that appear in this manual are trademarks or registered trademarks of the companies concerned. Note that "™" and "®" indications are not used.
- ▶ The company names, organization names and product names in this manual are trademarks or registered trademarks of the companies and organizations concerned.
- ▶ Soehnle Industrial Solutions does not guarantee that the WindowsDirect communication function will operate without problems on all PCs. Soehnle Industrial Solutions will accept no responsibility for any trouble that arises as a result of using this function. You are recommended to back up all important data and programs in advance.

Introduction

Model 9434, 9435 and 9436

Thank you for purchasing a Soehnle Professional electronic precision scale. The 9434, 9435 and 9436 series models are high performance electronic scales that we confidently recommend based on many years of precision scale manufacturing. While these models are of course capable of fast and accurate weighing, the 9435 and 9436 models all use the OneBloc cells and the 9434 models use our unique, newly developed and robust load cells, improving the reliability of the scales still further.

The new 9434, 9435 and 9436 series scales also feature operation keys for four directions, improving operating convenience and making the scales easier to use. These scales also feature a variety of other functions that make it more convenient for customers to use them for their own applications, including the Windows-Direct communication function, which enables measuring results to be transferred to a PC without installing any software.

To ensure that you can make full use of the performance and functions of your 9434, 9435 and 9436 series scale, read this instruction manual carefully and use the scale correctly in accordance with the directions in the manual. When you have finished reading the manual, keep it in a safe place together with the scale so that you can refer to it at any time.

For information on the following points, please contact your Soehnle Professional scale representative:

- Product warranty
- After sales service



Where can I find a dealer close to me?

Based on ZIP codes you can search on our Webpage www.soehnle-professional.com for a dealer in your area.

How to Find the Information You Need

Example Page

Notes

Information to help use the scale correctly.

Menu operation

Depiction of the display

Reference

Continued on next Page

10. Connection & communication with peripheral devices

Convenient Functions Relating to Output

■ Printing / Outputting Continuously (Continuous Output Function)

This function allows displayed weight readings to be automatically output continuously in the same timing as the display refresh cycle (approximately 100 msec intervals) while weighing, without having to press **PRINT**.

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

1

Press **PRINT** for about 3 seconds in the weighing mode.

2

Select the continuous output function.

UNIT
▲
FUNC

[APL PRN] → [UNIT] → [S] → [UNIT] → [FUNC]

[SEQ PRN]

Stability Mark	Continuous Output Function
Lit	ON
Unlit	OFF

→

SEQ PRN

When ON is set the stability mark is lit.

3

Change the setting.

Pressing **PRINT** alternately sets the ON and OFF settings.

MENU
ENTER

[SET]

→

SET

→

SEQ PRN

When ON is set the stability mark is lit.

If OFF is selected, perform ▶ step 6.

▶ Steps 7 onward are not necessary in this case.

▼ Continued on next page

10

CONNECTION & COMMUNICATION WITH PERIPHERAL DEVICES

119

5


What You Can Do

Methods & functions

This section lets you search for a method you would like to try or a function you want to know about.

▶ I want to weigh up to a fixed quantity by adding increments of the same sample (item to be weighed: powder, liquid, etc.) a little at a time.	Pouring Mode ▶ Page 83
▶ I want to make fine adjustments during weighing, like increasing the reaction speed of the display or stabilizing the display.	Easy Setting ▶ Page 84
▶ I want to use the scale to count items. ▶ I want to set unit weights (the weight of a single piece of the item being weighed) for multiple samples in advance.	Piece Counting ▶ Page 95
▶ I want to weigh in percentages.	Percentage Weighing ▶ Page 100
▶ I want to weigh a fixed amount of each of a number of different samples (items to be weighed: powder, liquid, etc.) and to mix these samples according to a formula.	Formulation ▶ Page 105
▶ I want to check excess or deficiency with respect to a target value and make "pass or fail" judgments accordingly.	Comparator Function ▶ Page 110
▶ I want to adjust the conditions under which the stability mark lights up.	Adjusting the Stability Mark ▶ Page 85
▶ I want to stabilize the display at zero when an empty sample container is placed on the pan.	Zero Tracking Function ▶ Page 76
▶ I want to automatically return the display to zero after weighing.	Auto Zero Function ▶ Page 78
▶ I want to automatically tare the scale (set the display to zero) after outputting a weight reading.	Auto Tare Function ▶ Page 80
▶ I want to tare the scale without waiting for the stability mark to light up.	Zero / Tare Timing Change Function ▶ Page 81

Various weighing methods



Zero point, and taring




What You Can Do

Methods & functions

► I want to adjust the scale so that it is very accurate after stabilization.	Span Calibration and Adjustment ► Page 60
► I want to carry out calibration and output a record.	Leaving a Record of Calibration ► Page 72
► I want to check the degree of drift in the scale's sensitivity.	Calibration Check ► Page 64
► I want to send data to a PC (e.g. to Excel).	WindowsDirect Communication Function ► Page 122
► After weighing, I want to output automatically upon stabilization.	Auto Print Function ► Page 116
► I want to output data continuously.	Continuous Output Function ► Page 119
► I want to output data either immediately or after stabilization.	Output Timing Change Function ► Page 144
► I want to change the format of the decimal point (comma or period) in the output data.	Selecting the Decimal Point Display Symbol ► Page 44
► I want to add the scale model name, ID and other information to weight readings.	GLP Output Function ► Page 158
► I want to display weights in units other than g (grams).	Switching Units ► Page 43 Setting the Units ► Page 90
► I want the power to turn off automatically when I am not using the scale.	Auto Power-Off Function ► Page 154
► I want to go directly into weighing mode when the power is switched ON.	Setting the Startup Display ► Page 155

Calibration



Printing / output



Miscellaneous

Safety Precautions

To be strictly observed

To ensure that you use the scale safely and correctly, read the following precautions carefully and observe them.

The levels of danger and damage that will arise if the scale is used incorrectly are classified and indicated as shown below.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor to moderate injury or equipment damage.

Precautions are classified and explained by using one of the symbols below, depending on the nature of the precaution.



Instructions

Indicates an action that must be performed.



Prohibitions

Indicates an action that must NOT be performed


CAUTION



Prohibitions

Never disassemble, modify or attempt to repair this product or any accessory.


You could sustain an electric shock or the product could operate abnormally.
If you believe that the scale has failed, contact your Soehnle Professional representative.



Prohibitions

Do not use the scale outdoors or anywhere where it will be exposed to water.

You could sustain an electric shock or the product could operate abnormally.



Instructions

Use the scale with the specified power supply and voltage.

Using the scale with an incorrect power supply or voltage will lead to fire or trouble with the scale. Note also that if the power supply or voltage is unstable or if the power supply capacity is insufficient, it will not be possible to obtain satisfactory performance from the scale.



Instructions

If you detect anything abnormal (e.g. a burning smell) disconnect the AC adapter immediately.

Continuing to use the scale with an abnormality could lead to fire or an electric shock.

Safety Precautions

To be strictly observed



Prohibitions

Do not connect anything other than peripheral devices specified by Soehnle Professional to the scale's connector.

If you do, the scale may stop working normally.
In order to avoid trouble, always connect peripheral devices in accordance with the directions in this manual.



Prohibitions

Do not use the scale anywhere exposed to explosive, combustible or corrosive gases.

This could cause fire or trouble.

PRECAUTIONS ON USE




Prohibitions

Avoid locations where the scale will be exposed to any of the following.

You may not be able to obtain correct weight readings.


- ▶ Air flow from an air conditioner, ventilator, door or window
- ▶ Extreme temperature changes
- ▶ Vibration
- ▶ Direct sunlight
- ▶ Dust, electromagnetic waves or a magnetic field



Instructions

Install the scale on a strong and stable flat table or floor.


Placing the scale in an unstable site could lead to injury or trouble with the scale.
When selecting the installation site, take into account the combined weight of the scale and the item to be weighed.



Instructions

Treat the scale with care and respect.

The scale is a precision instrument. Subjecting it to impacts could cause it to fail.
When moving the scale, remove pan and pan supporter. Grasp it firmly with both hands to carry it. If the scale has to be stored for a long time, store it in the packaging box in which it was delivered.



Instructions

After a power outage, turn the power back ON.

When a power outage occurs, the power is shut off automatically. Therefore, begin operation from "Turning the Power ON" (▶ Page 32) again.



Instructions

Use the correct weighing units.

Using incorrect weighing units can lead to accidents as a result of weighing errors.
Check that the weighing units are correct before starting weighing.

Soehnle Professional Scales and 21 CFR Part 11

21 CFR Part 11

21 CFR Part 11, Electronic Records, Electronic Signatures, Final Rule (often referred to as Part 11) is the United States Food and Drug Administration (FDA) regulation affecting computer resources and electronic records that are used for any document that is required to be kept and maintained by FDA regulations.

Requirements concerning computer resources security are key elements in Part 11. The controls implemented as a result of security related requirements are intended to result in trusted records.

Soehnle Professional CLASS-Balance Agent

Soehnle Professional provides a means for compliance with 21 CFR Part 11 with Soehnle Professional CLASS-Balance Agent software, part of a comprehensive laboratory data management system, Soehnle Professional CLASS Agent.

Ask your Soehnle Professional representative about it.

Soehnle Professional WindowsDirect Function

When Soehnle Professional scales are integrated with laboratory software by means of our WindowsDirect function, no communication software is required or used.

The Soehnle Professional scale functions as a primary device in the system, just as a keyboard, mouse or other data entry hardware does. For this reason, system validation and compliance may be greatly simplified with the use of Soehnle Professional scales.

Two-way Communication

Soehnle Professional scales have always been computer friendly and they can be set up for bi-directional communication as part of a fully automated production system or LIMS.

This manual includes the command codes and information needed by programmers to integrate Soehnle Professional scales with their software.

Action for Environment

(WEEE)

To all of Soehnle Professional equipment in the European Union:

Equipment marked with this symbol indicates that it was sold on or after 13th August 2005, which means it should not be disposed of with general household waste. Note that our equipment is for industrial/professional use only.

Contact Soehnle Professional service representative when the equipment has reached the end of its life. They will advise you regarding the equipment take-back.

With your co-operation we are aiming to reduce contamination from waste electronic and electrical equipment and preserve natural resource through re-use and recycling.

Do not hesitate to ask Soehnle Professional service representative, if you require further information.



WEEE Mark

Table of Contents

Soehnle Professional Scales 9434, 9435 and 9436

1. Before Weighing

Name and Function of Components	16
9435/9436 series	16
9434 Serie	17
Operation Keys	17
Menu Operation Keys	19
Display Panel	20
Numeric valve area	22
Installation	23
Choosing the Installation Site	23
Unpacking and Delivery Inspection	25
Installing the Components	27
Adjusting the Level of the Scale	30
Turning the Power ON	32
Warming Up	34
Performing Span Calibration	35

2. Using the Scale

Weighing	40
Outputting Weight Readings	42
Selecting the Display	43
Switching Units	43
Selecting the Minimum Number of Displayed Digit	43
Selecting the Decimal Point Display Symbol	44
Ending Weighing	46
Turning the Power OFF	46

3. Menu Settings

What is the Menu?	48
The Structure of the Menu	48

Menu Map	49
Instruction Manual	49
Menu Operation Key Symbol	49
Basic Menu Operations	50
Entering Numerical Values	51
Changing the Numerical Value	51
Changing the Position of the Decimal Point	52
Convenient Functions for Menu Setting	53
Returning to the Default Settings (Menu Reset) ...	53
Prohibiting Changes to the Menu Settings (Menu Lock)	44
Outputting the Menu Setting Information	55

4. Calibration

Before Starting Calibration	58
Span Calibration and Adjustment	60
Calibration Check	64
Calibration of the Internal Weight (9436 only) ...	69
Leaving a Record of Calibration	72
Example Printout of a Calibration Record	72
Setting Output of a Calibration Record	73
Setting a Scale ID	74

5. Functions Relating to Taring

Zero Tracking Function	76
Auto Zero Function	78
Auto Tare Function	80
Zero / Tare Timing Change Function	81

Table of Contents

Soehnle Professional Scales 9434, 9435 and 9436

6. Adjusting Response and Stability

Selecting the Weighing Mode	82
Selecting the General Weighing Mode	83
Selecting the Pouring Mode	83
Easy Setting of Response and Stability	84
Adjusting the Stability Mark	85
Setting the Stability Detection Range	85
Setting the Stability Mark Lighting Timing	86

7. Setting Units

Units that can be Displayed and Conversion	88
Factors	88
Selecting Units to Display	88
Setting User-Specified Units	90
Conversion Factors	90
Minimum Indication	92

8. Application Function Mode

Counting Pieces by Weight (Piece Counting)	95
Preparation for Piece Counting (Including Setting the Unit Weight)	95
Counting Numbers of Pieces	97
Changing a Unit Weight, or Adding a New Unit Weight	99
Percentage Weighing	100
Preparation for Percentage Weighing	100
Weighing Percentages	104
Formulation	105
Performing Formulation	105
Outputting Component Numbers	108
Outputting the Gross Weight	109

9. Comparator function

Target Mode	111
Checkweighing Mode	113

10. Connection and Communication with Peripheral Devices

Convenient Functions Relating to Output	116
Printing / Outputting Automatically (Auto Print Function)	116
Printing / Outputting Continuously (Continuous Output Function)	119
WindowsDirect Communication Function	122
What Is the WindowsDirect Communication Function?	122
Setting the Function	122
Troubleshooting the WindowsDirect Communication Function	128
Connecting to a PC (RS-232C)	129
Cable Connection Method	129
Data Format	130
Command Codes	132
Connecting to a Printer	137
Communication Settings	139
Standard Settings (MODE)	140
User-Specified Settings	140
Output Timing Change Function	144

Table of Contents

Soehnle Professional Scales 9434, 9435 and 9436

11. Maintenance

Maintaining the Scale	146	Reading the Menu Map	166
Removing the Glass Door	147	Main Menu	166
Inspection	148	Data Output Menu	168
Daily Inspections	148	Unit Setting Menu	169
Periodic Inspections	149	Calibration Menu	169
About Weights	150	Zero / Tare Menu	169
Types of Weight and Their Selection	150		

12. Troubleshooting

What to Do If	152
Responding to Messages	153

13. For Your Information

Turning the Power ON and OFF	154
Auto Power-Off Function	154
Setting the Startup Display	155
Backlight ON/OFF (9434 only)	156
Changing the Password	157
GLP Output Function	158
Setting the GLP Output Function	158
Setting a Scale ID	160
Specifications	161
9435/9436 series	161
9434 Serie	162
Maintenance Parts	163
9435/9436 series	163
9434 Serie	164
List of Functions That Can Be Used in	
Combination	165
Menu Map	166

1. Before Weighing

Name and Function of Components

■ 9435/9436 series

The 9435/9436 series comprises toploading electromagnetic scales with OneBloc weighing mechanism.

► Main body

Pan

Place the object to be weighed here.

Display panel

Shows the weighing results, information for making function settings, the current function setting, errors, codes and other information.

► Page 20

Level

Indicates the level of the scale.

► Page 30

Windbreak (included with small pan models only)

Even a slight breeze may affect measurement, so the windbreak is provided to avoid air movements in the surroundings influencing the weight reading.


Product label

The model name and serial number are stated here.

Menu operation

Used to specify function settings and menu operations.

► Page 19



Operation keys

Used to tare the scale, perform calibration and print.

► Page 18

Level screws

Adjust to level the scale.

► Page 30

► Back of the unit

Kensington Security Slot

This is a slot in which a lock can be fitted for anti-theft purposes. The socket conforms to the specifications of the Kensington company.

DATA I/O connector

Used to connect to a printer (e.g. EP-80 or EP-90).


► Page 137

RS-232C connector (9-pin socket)

Used to make a serial connection to a PC or other equipment.

DC IN connector

Used to connect an AC adapter for power supply.



Ground terminal

Connect this terminal to ground if necessary.

1. Before Weighing

Name and Function of Components

■ 9434 series

The 9434 series comprises load cell type toploading scales that can be powered by batteries as well as AC power.

► Main body

Level

Indicates the level of the scale.

► Page 30

Display panel

Shows the weighing results, information for making function settings, the current function setting, errors and other information.

► Page 20

Operation keys

Used to tare the scale, perform calibration and print.

► Page 18

Menu operation keys

Used to specify function settings and menu operations.

► Page 19

Level screws

Adjust to level the scale.

► Page 30

Pan

Place the object to be weighed on here.

Product label

The model name and serial number are stated here.

► Underside of the unit

Battery compartment

Six size AA alkaline batteries

► Page 33

► Back of the unit

DATA I/O connector

Used to connect to a printer (EP-80, EP-90, etc.).

► Page 137

RS-232C connector (9-pin socket)

Used to make a serial connection to a PC or other equipment.

DC IN connector



To run the scale on AC power, connect the AC adapter here.

Kensington Security Slot

This is a slot in which a lock can be fitted for anti-theft purposes. The socket conforms to the specifications of the Kensington company.


Ground terminal

Connect this terminal to ground if necessary.



1. Before Weighing

Name and Function of Components



■ Operation Keys

During Weighing				
No.	Key	Press Once and Release ...	Press and Hold for About 3 Seconds ...	During Menu Operation
1	[BREAK]	Switch between the operation and standby modes	–	Suspends calibration / numerical value entry
2	[CAL]	Performs calibration	Enters the calibration menu	–
3	[O/T]	Tares the scale (setting it to zero)	Opens the zero / tare menu	–
4	[PRINT]	Outputs the weight reading to a peripheral device (printer or PC)	Opens the data output menu	–

1. Before Weighing

Name and Function of Components

















■ Menu Operation Keys

During Weighing				
No.	Key	Press Once and Release ...	Press and Hold for About 3 Seconds ...	During Menu Operation
5	[MENU/ENTER]	Displays the main menu	Shows the menu displayed last	Confirms and sets the displayed entry
6	[UNIT] ▲	<ul style="list-style-type: none"> ▶ In the weighing mode: Used to select the unit ▶ When piece counting: Displays the unit weight ▶ When performing percentage weighing: Displays the reference weight 	<ul style="list-style-type: none"> ▶ In the weighing mode: Opens the unit setting menu ▶ When piece counting: Used to select the item number ▶ When performing percentage weighing: Used to select the percentage reference 	<ul style="list-style-type: none"> ▶ Scrolls backward through menu options ▶ When entering numerical values: Increases the value
7	[FUNC] ▼	Switches between the weighing mode and the application function mode	Selects the minimum number of displayed digits	<ul style="list-style-type: none"> ▶ Scrolls forward through menu options ▶ When entering numerical values: Reduces the value
8	[Res] ◀	The response of the display is increased.	–	<ul style="list-style-type: none"> ▶ Takes you to a higher level in the menu hierarchy ▶ When entering numerical values: Moves the focus one digit to the left ▶ Suspends menu operation
9	[Stb] ◀	The stability of the display is increased.	–	<ul style="list-style-type: none"> ▶ Takes you to a lower level in the menu hierarchy ▶ When entering numerical values: Moves the focus one digit to the right

1. Before Weighing

Name and Function of Components

■ Display Panel

Display	Name	Description	See:
	Battery symbol	Lights up when the power supply voltage is low, for example when the battery voltage is low.	► Page 34
	Zero tracking symbol	Lit when the zero tracking function is set ON.	► Page 76
	Weight symbol	This symbol is lit during calibration.	► Page 60 ► Page 61
	Easy setting indicator	Indicates what level the response and stability are currently set to.	► Page 84
	Pouring symbol	Lit when the pouring mode is set.	► Page 85
	Formulation symbol	Lit during mixing measurement (formulation) operations.	► Page 105
	Menu lock symbol	Lit while the menu is locked.	► Page 44
	Menu operation key symbol	During menu operation, indicates which of the menu operation keys can be used.	► Page 49
	Auto print symbol	Lit when the auto print function is set.	► Page 116
	Win symbol	Lit when the WindowsDirect communication function has been set.	► Page 122
	Communication symbol	Indicates that data is being exchanged with an external device.*2	-
	Comparator symbol	When the comparator function (Checkweighing) has been set, indicates the comparison judgment.	► Page 110
	Stability mark	Lit when the weight reading is stable. Lit when the option currently set in menu setting is displayed.	► Page 48 ► Page 85
	Minus symbol	Lit when the weight reading is negative.	
	Zero symbol	Indicates that the scale is set exactly to "Zero" with the zerosetting function (+/-0.25e: e = verification scale interval).*1	
	Ready symbol	Lit during the standby mode (9435/9436 series only). During weighing, lit to indicate the ready to weigh status, for example when using the formulation function.	► Page 46 ► Page 105
	Number Symbol	Lit when it is possible to enter numerical values.	► Page 51

1. Before Weighing

Name and Function of Components

Display	Name	Description	See:
*	Hold symbol	Lit when a value that is not the real-time weight reading (for example the indication of the unit weight in piece counting) is displayed.	► Page 97 ► Page 104
NET	Net weight symbol	Indicates that the weight reading displayed in mixing measurement (formulation) is the net weight of the current component with the weight of the container and prior components. Also indicates that a measuring operation is in progress.	► Page 105
G	Gross weight symbol	Indicates that the weight reading displayed in mixing measurement (formulation) is the total weight of all of the components of the mixture with the weight of the container subtracted.	► Page 105
1 2 3 4 5	Item number indication	Shows the item number in the piece counting mode.	► Page 97
▼	Inverse triangle symbol	When this symbol is lit when changing the position of the decimal point in the conversion factor with the of userspecified units, numerical values can be entered without a decimal point.	► Page 51
PCS	Piece counting symbol	Lit while the piece counting mode is in effect.	► Page 97
% 0	Specific percentage weighing symbol	Lit when the specific percentage reference has been set for percentage weighing.	► Page 100
%	Percentage weighing symbol	Lit during percentage weighing.	► Page 104

^{*1} Applicable to only a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

^{**2} Using a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval, when the weight value is unstable this symbol blinks with no weight data output, when the weight value becomes stable this symbol lits with weight data output.


1. Before Weighing

Name and Function of Components

■ Numeric valve area

Using a verified scale as a legal measuring instrument in the EU:

Model with EC Type Approval, Bracket appears at Scale Interval (d) digit as below.



Bracket racket

1. Before Weighing

Installation

■ Choosing the Installation Site

The measuring performance of the scale is greatly influenced by the environment where it is installed.

Observe the following points to ensure safe and accurate weighing.

CAUTION



Prohibitions

Do not use the scale anywhere exposed to explosive, combustible or corrosive gases.

This could cause fire or trouble.



Instructions

Use the correct power supply and voltage with the scale.

Using an incorrect power supply or voltage with the scale will lead to fire or trouble with the scale.

Note also that if the power supply or voltage is unstable or if the power supply capacity is insufficient, it will not be possible to obtain satisfactory performance from the scale.


PRECAUTIONS ON USE



Prohibitions

Avoid locations where the scale will be exposed to any of the following.

- Air flow from an air conditioner, ventilator, door or window



1. Before Weighing

Installation


PRECAUTIONS ON USE




Prohibitions

Avoid locations where the scale will be exposed to any of the following.


- Extreme temperature changes




- Vibration from surroundings or nearby equipment



- Direct sunlight



- Dust, electromagnetic waves or a magnetic field



Instructions

Install the scale on a strong and stable flat table or floor.

Placing the scale in an unstable site could lead to injury or trouble with the scale.
When selecting the installation site, take into account the combined weight of the scale and the item to be weighed.


1. Before Weighing

Installation


■ Unpacking and Delivery Inspection

The items packed will differ depending on the model of scale ordered.
Check that all of the items indicated below are included in the package, and that nothing has been damaged. The numbers in the boxes [] indicate the quantity of each item.

► 9435 Series (large pan model)



► 9435/9436 series (small pan model)



1. Before Weighing


Installation

■ Unpacking and Delivery Inspection


The items packed will differ depending on the model of scale ordered.

Check that all of the items indicated below are included in the package, and that nothing has been damaged. The numbers in the boxes [] indicate the quantity of each item.

► 9435 Series (large pan model)



► 9434-Series (small pan model)



1. Before Weighing

Installation

1

BEFORE WEIGHING

■ Installing the Components


The procedure for fitting the components differs depending on the model of the scale.

- ▶ 9435 Series (large pan model)


1 Attach the protective cover

When using the scale in a rough dirty environment it must be protected with the protective cover.


- ▶ Remove the two screws at the top of the scale and remove the bottom plate.
- ▶ Peel off the paper; below is the exposed glued surface.
- ▶ Pull the protective cover over the scale.
- ▶ Mount the sub-plate in order to fix the protective cover between the plate and the scale; then tighten the two screws.
- ▶ Press the parts with glued surfaces firmly together in order to attach them seamlessly on display.



2 Fit the four pan supporter caps.



3 Place the pan on the pan supporters.




1. Before Weighing

Installation

- ▶ 9435/9436 series (small pan model)
- ▶ 9435/9436 series (carat model)

1 Fit the underplate.

Open the glass door and insert the underplate slowly while tilting it.
Be careful not to knock against the surroundings.




2 Fit the pan ring.

3 Place the pan supporter.

4 Place the pan on the pan supporters.

Align the two pan notches with the left and right on the scale main body.



5 Attach the protective cover of the control panel (display and operator panel).

When using the scale in a rough dirty environment it must be protected with the protective cover.

- ▶ Peel off the paper; below is the exposed glued surface.
- ▶ Attach the protective cover to the control panel.
- ▶ Press the parts with glued surfaces firmly together in order to attach them seamlessly on display.

1. Before Weighing



Installation

- ▶ 9434 series (common to large pan models and small pan models)

1 Fit the pan ring.

- ▶ Align the two pan ring notches with the left and right on the scale main body, and engage the four projections on the pan ring in notches in the scale main body.
- ▶ Turn the pan ring counterclockwise until it clicks into place.

Notches in the pan ring



CAUTION



Turn the pan ring until it clicks into place.


Instructions

If the pan ring is not turned sufficiently, it will come into contact with the pan, and the display of the scale will become unstable.

2 Place the pan supporter.

3 Place the pan on the pan supporter.

Align the two pan notches with the left and right on the scale main body.



1. Before Weighing

Installation



■ Adjusting the level of the scale

The level of this scale is maintained by three-point support involving a single fixed foot at center rear on the underside of the main body and two level screws on left and right at the front of the underside of the main body. The large pan model also has level screws on left and right at the back, but they are used in an auxiliary role to prevent the scale from tilting when a heavy sample is placed on the pan.

INFO

OPERATION OF THE LEVEL SCREWS

Turning the level screws clockwise, as viewed from above, extends them and raises the scale, while turning them counterclockwise retracts them and lowers the scale.



Level the scale by following the procedure below.

1. Before Weighing

Installation

- 1** Turn all the level screws (total of four at front and rear) counterclockwise as viewed from above until they come to a gentle stop.

The scale will now be tilting toward the front, with the auxiliary level screws at the back of the large pan model lifted off the installation surface.

- 2** Adjust the two level screws at the front so that the air bubble in the level becomes centered in the left/right direction.

At this stage it doesn't matter if the air bubble isn't centered in the front/rear direction.

If the air bubble is left of center



Turn the front right level screw clockwise.



If the air bubble is right of center



Turn the front left level screw clockwise.



- 3** Turn both the level screws at the front in the same direction at the same time to center the air bubble in the level in the front/back direction.

Adjust so as to bring the air bubble into the center of the circle.

On turning the two level screws at the front in the clockwise direction ...



The bubble moves toward the front.



On turning the two level screws at the front in the counterclockwise direction ...



The bubble moves toward the back.



With the large pan model ...

- 4** Turn both of the auxiliary level screws at the rear clockwise to extend them to the point where they make light contact with the installation surface.


Note that if you overextend the auxiliary level screws at the rear the scale will become unstable.

1. Before Weighing

Installation


■ Turning the Power ON

1 Insert the plug of the AC adapter into the DC IN connector on the back of the scale.


2 Connect the AC adapter to the power outlet (with the 9434 series, press ).

The display will automatically go through the changes indicated below, ending with the OFF display.

The first information displayed is the software version number. Depending on the product, this may differ from the example shown below.



(This is the scale's self check display.)



INFO

FOR THE 9436 SERIES...

An operation check on the internal weight mechanism is performed automatically. During this check, a small motor noise will be heard.

INFO

FOR THE 9434 SERIES ...

The software version is not displayed.

INFO

IF "ERR H" IS DISPLAYED...

See "Responding to Messages"

► Page 153

3 Press  ( with the 9434 series).

All segments will light up momentarily, then the gram display will be shown.

1. Before Weighing

Installation

- Using batteries (9434 series only)

1 Remove the pan and pan supporter.


CAUTION



Prohibitions

Do not remove the pan ring.

Attempting to do so could break it. The pan ring protects the weighing mechanism when the scale is turned over.



2 Turn the scale upside down.

3 Press the two catches on the battery compartment simultaneously in the direction indicated by the arrows.

The cover will come off.


CAUTION



Prohibitions


Do not open covers where a seal is affixed.

On no account open the covers inside the battery compartment that have seals affixed to them.



4 Insert the batteries and replace the cover.

Take care to insert the batteries with the correct polarity.



5 Press ①

The display will automatically go through the changes indicated below, ending with the OFF display.




(This is the scale's self check display.)

1. Before Weighing

Installation

6 Press ⓘ

The whole display will light up momentarily, then the gram display will be shown. If  (the battery symbol) lights up at this point, the probable cause is that the battery voltage is low. Replace the batteries with new ones.

INFO

IF YOU ARE NOT GOING TO USE THE SCALE FOR A LONG TIME (A MONTH OR LONGER) ...

In order to prevent damage by liquid leakage from the batteries, remove them from the battery compartment.

► Page 153

■ Warming Up

Before performing span calibration on the scale or measuring its accuracy, you must ensure that it is in a stable state.

When stabilizing the scale, it is important that its temperature is stable.

Put the scale in weighing mode (for example showing the gram display) and leave it with the power ON for at least an hour (two hours for the carat models 9436.04.001, 9435.04.001.) in advance of calibration.

This is called "warming up".

With the 9435/9436 series

Warming up is also accomplished in the standby mode.

For details on the standby mode, see "Turning the Power OFF".

(* The standby mode is a function available with the 9435/9436 series only. It is not featured on the 9434 series.)

Warming up on the standby mode,
see "Turning the Power OFF"

► Page 46

With the 9434 series

When the auto power-off function operates, the power is shut off completely. Before warming up for calibration, cancel the auto power-off function so that it cannot operate.

For details on the auto power-off function, see "Auto Power-Off Function"

(* The standby mode is a function available with the 9435/9436 series only. It is not featured on the 9434 series.)

Auto power-off function,
see "Auto Power-Off Function"

► Page 154

1. Before Weighing

Installation

■ Performing Span Calibration

Always perform span calibration for a scale after moving it. Weights are required for span calibration of the 9435 and 9434 series. Before performing span calibration, warm up the scale in advance. Also, carry out the adjustment at a location where there are few people moving around and there is no air flow or vibration.

► 9436 Series

For details on weights, see "About Weights"

► Page 150

1

Press 

Calibration using the internal weight starts automatically.


INFO

IF "WAIT" IS DISPLAYED ...

The calibration record is being output. When output has finished, span calibration will start automatically.

INFO

IF "BUSY" IS DISPLAYED ...

There is something placed on the pan. When this item is taken off the pan, span calibration will start automatically. To cancel scan calibration, press 

INFO

IF "ERR H" IS DISPLAYED ...


See "Responding to Messages"
► Page 153

INFO


IF "ERR C" IS DISPLAYED...

Span calibration was not completed for one of the following reasons.

- There is too large a discrepancy between the zero point of the scale and the sensitivity.
- A container has been placed on the pan.
- The pan is not on the scale.
- There is too large a discrepancy in the value of the internal weight.

Press  and redo the operation from the beginning. If even on doing this the same display reappears, calibrate the internal weight.

► Page 69



"END" will be displayed and the scale will return to the weighing mode.

1. Before Weighing

Installation

CAUTION



Instructions

If calibration doesn't end normally and the balance stops, do not move it nor leave it as it is.

Moving the scale in such a condition may cause failure because the internal weight is not held correctly. Before moving the scale, be sure to turn the power on and start it up correctly (so that the internal weight is correctly held).

► 9435/9434 series

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

1

Press 

The weight value will flash.

INFO



IF "WAIT" IS DISPLAYED ...

The calibration record is being output. When output has finished, span calibration will start automatically.





INFO

IF "BUSY" IS DISPLAYED ...

There is something placed on the pan. Take the item off the pan and follow the procedure below. To cancel scan calibration, press   with the 9434 series).

INFO

IF NO OPERATION IS PERFORMED WITHIN 60 SECONDS ...

"ERR C" (calibration error) is displayed. Press   with the 9434 series) and repeat the operation from the beginning.

1. Before Weighing


Installation

2 Enter the weight value.

If necessary, change the weight value to match the weight that will be used for calibration. If there is no need to change it, proceed to ► step 3.



(If necessary enter the weight value.)



"Entering Numerical Values"

► Page 51



For details on the weight values that can be entered, see "Specifications"

► Page 161

With models that don't feature the windbreak

3 Place the calibration weight on the pan.

Wait until the flashing weight value display changes to a flashing zero.



IF "ERR C" IS DISPLAYED ...

Span calibration was not completed for one of the following reasons.


- There is too large a discrepancy between the zero point of the scale and the sensitivity.
- A container has been placed on the pan.
- The pan is not on the scale.
- The wrong weight has been placed on the pan.
- No operation has been performed within 60 seconds of the flashing weight value or zero display.

Press (with the 9434 series) and repeat the operation from the beginning.

INFO

4 Take the weight off the pan.

"END" will be displayed and the scale will return to the weighing mode.



1. Before Weighing

Installation

With models that feature the windbreak


3 Place the calibration weight on the pan.

Open the glass door in the windbreak, place the weight on the pan, and shut the glass door again. Wait until the flashing weight value display changes to a flashing zero.

SHUT THE GLASS DOOR FULLY.



INFO

After placing a weight on the pan or removing a weight from the pan, check that the glass door is fully shut.



4 Take the calibration weight off the pan.

Open the glass door in the windbreak, remove the weight from the pan and shut the glass door again. "END" will be displayed and the scale will return to the weighing mode.



The procedure described above is the default standard span calibration procedure.

For details, see

"4. Calibration"

► Page 58

Memo

1

BEFORE WEIGHING

2. Using the Scale

Weighing

1 Enter the weighing mode.

INFO

WHAT IS THE WEIGHING MODE?



The scale is in the state where it indicates the units (for example grams) of the weight on the pan.

To establish the weighing mode, follow the steps below depending on the current status of the scale.

Status of the Scale

To Establish the Weighing Mode ...

The display is off.

Press  ( with the 9434 series). When the "OFF" indication appears or all segments are lit, press any key.


"OFF" indication, all segments lit, or **READY** (ready symbol) lit

Press any key.




The application function mode is established.

Press .

A menu indication is displayed.

Press  for about 3 seconds.

The scale is accepting numerical value entry.

Press  ( with the 9434 series) to cancel numerical value entry, then press  for about 3 seconds.

With models that don't feature the windbreak


2 Place a container on the pan.

3 Once the display has stabilized (→ has lit), press .

The indication changes to zero.

Container

0/T key



4 Insert the sample (item to be measured) into the container.

5 When the display has stabilized, → (the stability mark) lights up, read the display.


INFO

IF AN INDICATION LIKE "OL" OR "-OL" APPEARS DURING MEASUREMENT ...

See "Responding to Messages"
▶ Page 153

Sample

Display



2. Using the Scale

Weighing

With models that feature the windbreak

2 Place a container on the pan.

Open the glass door in the windbreak, place the container on the pan and shut the glass door again.

3 Once the display has stabilized (➡ has lit), press **→0/T←**.

The indication changes to zero.

4 Insert the sample (item to be measured) into the container.

Open the glass door of the windbreak, place the sample (item to be weighed) on the pan and shut the glass door again.

5 When the display has stabilized, ➡ (the stability mark) lights up, read the display.

INFO

SHUT THE GLASS DOOR FULLY.

Check that the glass door is fully shut before reading the scale display.



INFO

AVOID DOING THE FOLLOWING:

- ▶ Putting your hand inside the glass door of the windbreak
- ▶ Touching the container or sample with bare hands
- ▶ Weighing samples (items to be weighed) of different temperatures

The heat will lead to convection, and this may make the scale display unstable. Use forceps or gloves to carry containers and samples.

When dealing with samples (items to be weighed) at different temperatures, eliminate the temperature difference by leaving the samples around the pan inside the glass door before weighing.



2. Using the Scale

Outputting Weight Readings

PC and printer

When the scale is connected to a PC and a printer (option), you can output a weight reading, settings, and so on for each measurement.

The WindowsDirect communication function is convenient for output to a PC.

- ▶ When the GLP output function is set to OFF, only the weight reading is output.
- ▶ When the GLP output function is set to ON, the following information is output.

Data output function


see "Windows Direct function"

▶ Page 122

Data output function

GLP data output function

▶ Page 158



Example printout from printer
(When the GLP output function
is set to ON)

2. Using the Scale

Selecting the Display

■ Switching Units

You can display different units from among those set to be available.

1 Press **UNIT** in the weighing mode.



When the scale is shipped from the factory, the only unit registered is grams. To be able to switch to other units, you must first register the units you wish to use.

When user-specified units have been selected, the characters and symbols that indicate the units don't light up.

INFO

UNIT DISPLAY AFTER RESTARTING

When the power is turned off and back on, the scale starts up displaying the units that were in use before the power was turned off.



"Selecting Units to Display",

► Page 88

■ Selecting the Minimum Number of Displayed Digit

If necessary, the minimum number of displayed digit can be reduced by one digit.

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU:
Model with EC Type Approval

1 Press **FUNC** for about 3 seconds.

The minimum number of displayed digit will be reduced by one.



2 Press **FUNC** again for about 3 seconds.

INFO

DISPLAY AFTER SELECTION

The decimal place doesn't change. Note also that when one digit is removed the display area for the final digit appears as a blank.



The minimum number of characters displayed will return to the original setting.

2. Using the Scale

Selecting the Display


■ Selecting the Decimal Point Display Symbol

The decimal point can be displayed as either "." (a period) or "," (a comma).

1 Press in the weighing mode.


This opens the main menu.

2 Select decimal point display setting.



3 Select the decimal point display symbol.

To select "." (period):



To select "," (comma):



INFO

WHEN OUTPUTTING TO THE ER-50/EP-60A ELECTRONIC PRINTER (OLD TYPE) ...

Do not select "," (comma). The printer may not print it correctly.

2. Using the Scale

Selecting the Display

4 Confirm and return to the weighing mode.

 [5E7] → Press  for about 3 seconds.

The way the decimal is displayed has now changed.

INFO

SELECTING THE DECIMAL POINT DISPLAY SYMBOL

When the decimal point display is changed, the decimal point changes accordingly in data output to external devices such as printers.



To select the period



To select the comma



2. Using the Scale

Ending Weighing


■ Turning the Power OFF

1 Establish the weighing mode.

see "Weighing"


► Page 40

2 Press

If the status described below is not established, press  again.


With the 9435/9436 series ...

READY (the ready symbol) will light and the standby mode will be established. Normally, leave the scale on standby in this state until the next weighing. To shut the power off completely, disconnect the AC adapter.



INFO

WHAT IS THE STANDBY MODE?

This is the status in which the scale stands by, saving electricity although it can still be used right away. On pressing  in the weighing mode the display is turned off, **READY** (the ready symbol) is lit and the power saving status (standby mode) is established. During the standby mode, the interior of the scale is powered and in the warming-up status, ready for immediate use.

(* stand-by mode only available for the 9435/9436 series)

With the 9434 series ...

The power is shut off. The standby mode is not established. Normally, leave the scale in this state until the next weighing. If batteries are installed in the scale and it is not going to be used for a long time, remove the batteries.



CAUTION



Prohibitions

While [WAIT] or [SET] is displayed, on no account disconnect the AC adaptor.

There is a risk that data in the scale will be corrupted.

Memo

3. Menu Settings

What is the Menu?

With the 9434/9435/9436 series, the menu is used to efficiently select the right functions for the user's application.

■ The Structure of the Menu

The menu is divided into five groups according to the setting made.

Menu Group	Description
Main menu	Used to set the application function mode, comparator, stability adjustment, etc.
Calibration menu	Used to set the details for calibration
Zero / tare menu	Used to set the details for taring
Data output menu	Used to set the functions for transmitting data to a PC or outputting them to a printer
Unit setting menu	Used to set which units may be displayed in weighing mode

You can open each menu group by pressing the various operation keys and menu operation keys.




Within each menu group are a number of hierarchical menu levels.

You can move between levels in the menu hierarchy by pressing **RECALL** and **SET**.

You can scroll through the options within each level of the hierarchy by pressing **UNIT** or **FUNC**.

Arrangement of the Menu



3. Menu Settings

What is the Menu?

■ Menu Map

The menu map represents the organization of the menu options graphically to make it easy to understand. It is useful for quickly accessing the menu option you want to use.


Menu Map

For more on the menu map, see "Menu Map" and "Menu Map Sheet".


► Page 166

■ Instruction Manual


The instruction manual describes specific parts of the menu operations in a simplified form.



■ Menu Operation Key Symbol

On entering menu operation,  (the menu operation key mark) lights up.

The keys represented by lid segments can be used.



3. Menu Settings

Basic Menu Operations

1 Open the target menu from the weighing mode.

The method used to open a menu option differs depending on the group. For details on the methods used for menu opening from each group, see

“The Structure of the Menu”

► Page 48

2 Set menu options by pressing the menu operation keys.

The menu operation keys are used to set functions and to enter numerical values.


For details on how to operate the menu operation keys, see **“What is the Menu?”**

► Page 48

For details on the operating procedure for entering numerical values, see **“Entering Numerical Values”**

► Page 51

Menu operation keys



INFO

FOR A MENU OPTION THAT IS ALREADY SET ...

➡ (the stability mark) appears in the menu display.

3 Confirm and return to the weighing mode.

The operation after confirming the menu selection differs depending on the menu, and you will either be returned to the weighing mode automatically or will need to do it manually.

To return manually, press  for approximately 3 seconds.

INFO

IF YOU OPEN THE MENU AGAIN ...







The recently set menu option will be displayed first. Note also that, when the set menu option is displayed, ➡ (the stability mark) also appears.

3. Menu Settings

Entering Numerical Values

Numerical values sometimes have to be entered for menu settings, for example the weight value of a calibration weight, condition values for operating functions, the scale ID, passwords, etc.

- Operations of the operation keys

Operation Key	Operation During Numerical Value Entry
	Confirms the entered numerical value
	Increases the value of the digit to be entered (the flashing digit) Pressing this key while the decimal point is flashing shifts the decimal point to the left.
	Decreases the value of the digit to be entered (the flashing digit) Pressing this key while the decimal point is flashing shifts the decimal point to the right.
	Shifts the digit to be entered (the flashing digit) one digit to the left
	Shifts the digit to be entered (the flashing digit) one digit to the right
	Cancels entry

3

MENU SETTINGS

■ Changing the Numerical Value

As an example, here is the procedure for changing "120.000 g" to "200.000 g".

1 Enter the numeric value entry mode.

(the number symbol) lights and the leftmost digit (highest digit) in the range where the value can be changed flashes.



2 Press once.

The numerical value of the flashing digit increases by one, so that it changes from "1" to "2".



3 Press .

The flashing shifts to the second digit from the left.



3. Menu Settings

Entering Numerical Values

4 Press twice.

The numerical value of the second digit from the left decreases two times, so that it changes from "2" to "1" to "0".



5 Press .

This confirms the entered numerical value. The indication shown to the right remains displayed for several seconds, then the display automatically moves on to the next step.



■ Changing the Position of the Decimal Point

The position of the decimal point can only be changed when entering a conversion factor with the user-specified units.

"Conversion Factors"

► Page 90

As an example, here is the procedure for shifting the position of the decimal point one digit to the left, to change the displayed value from "100.000" to "10.0000".

1 Establish the numeric value entry mode.

(the number symbol) lights and the leftmost digit (highest digit) in the range where entry (change) is possible flashes.



2 Press several times until the decimal point flashes.





3 Press or several times.

This will move the decimal point to the left or right.



INFO

TO SET A NUMERICAL VALUE WITH NO DECIMAL POINT ...

Press  several times until  (the inverse triangle symbol) flashes.

4 Press .

This confirms the entered numerical value. The indication shown to the right remains displayed for several seconds, then the display automatically moves on to the next step.



3. Menu Settings

Convenient Functions for Menu Setting

■ Returning to the Default Settings (Menu Reset)

If you want to return the menu settings to the default settings, reset the menu. The default settings are indicated by asterisks in the menu map and on the menu map sheet.

Menu map
for default settings see here:

▶ Page 166




3

MENU SETTINGS

1 Press in the weighing mode.

This opens the main menu.

2 Select menu reset.



3 Enter the password.

The password is set to "9999" before shipment. If the default setting is not changed, enter "9999".



"Changing the Password"

▶ Page 157

"Entering Numerical Values"

▶ Page 51

4 Confirm.



The default menu settings are reinstated and the scale automatically returns to weighing mode.



3. Menu Settings

Convenient Functions for Menu Setting

■ Prohibiting Changes to the Menu Settings (Menu Lock)

In order to ensure that the menu settings are not changed by mistake, the person managing the scale controls the password and can prohibit menu operation. The default password is "9999". To change the password, see "Changing the Password".

"Changing the Password"
How to change the password is described here:


► Page 54

INFO

OPERATION IN THE MENU LOCK STATUS

Even when the menu is locked it is possible to perform calibration (CAL), change the weight value, and switch the weighing mode and application function (FUNC).

1

Press  until the display changes (about three seconds) while "OFF" is displayed after supplying power or while in the standby mode.



OFF display after supplying power

INFO

WITH THE 9434 SERIES THE SCALE DOESN'T GO INTO THE STANDBY MODE.

If the "OFF" display doesn't appear, see "Setting the Startup Display"

► Page 54



Standby mode

2

Enter the password.

"Entering Numerical Values"

► Page 54



3

Press 

The password will be accepted.

The menu will be locked and the display will return to the indication in step 1.



The menu lock symbol will light up.

If the password is wrong ...

The error message shown to the right will be displayed and the display will return to the indication in step 1.




3. Menu Settings

Convenient Functions for Menu Setting


4 Confirm.

On entering the weighing mode ...

 (the menu lock symbol) is shown in the display.

On performing prohibited operations ...

"LOCKED" is displayed and menu operation is not possible.



INFO

RELEASING THE MENU LOCK

To release the menu lock, perform steps 1 through 3 again.


■ Outputting the Menu Setting Information

You can output the menu settings to make a record of the scale settings.

1 Connect the scale to a PC or printer (option).

Connection and Communication with Peripheral devices


► Page 116



2 Press in the weighing mode.

This opens the main menu.

3 Select output of menu setting information.



To output the settings, proceed to step 4.
To cancel, press  ( with the 9434 series).

3. Menu Settings

Convenient Functions for Menu Setting

4

Confirm.




[WAIT]

On confirmation, the menu setting information is output to the PC or printer. On completion of output, the scale returns to weighing mode.



During output the communication symbol is lit.



Memo



MENU SETTINGS



4. Calibration

Before Starting Calibration ...

In order to weigh accurately with an electronic scale, the scale must be calibrated after it has been moved or if the room temperature has changed substantially. You are also advised to carry out calibration routinely (before use every day).

Before Starting Calibration

Two kinds of calibration operation are possible with the 9434/9435/9436 series: "span calibration" and the "calibration check", and for each of them you can select the use of either the internal weight (9436 only) or the external weight.

By registering either of these for , the registered operation can be started by just pressing .


Span calibration


Adjust to achieve correct scale sensitivity using either the internal weight (9436 only) or the external weight. Drift in the sensitivity is corrected (default setting).

Calibration check

Investigate the drift in the scale's sensitivity by using either the internal weight (9436 only) or the external weight.

INFO

The operation to calibrate the internal weight itself cannot be registered in .
To calibrate the internal weight itself, refer to "Calibration of the Internal Weight (9436 only)"
▶ Page 69

Use the following procedure to set the preferred operation for .

1


Press  for about 3 seconds.

This opens the calibration menu.

2

Select either "span calibration" or "calibration check".

Example of registering "span calibration using the internal weight"



Example of registering "span calibration using the external weight"



4. Calibration

Before Starting Calibration ...

INFO


E.CAL IS NOT APPLICABLE ...

Not applicable to a verified scale as a legal measuring instrument in the EU:
Model with EC Type Approval

Example of registering a "calibration check using the internal weight"



Example of registering a "calibration check using the external weight"



4

CALIBRATION

INFO


E.TEST IS NOT APPLICABLE ...

Not applicable to a verified scale as a legal measuring instrument in the EU:
Model with EC Type Approval

3

Confirm and return to the weighing mode.

MENU ENTER [SET] → Press []S for about 3 seconds.



"Span calibration" or "calibration check", whichever was selected in step 2, is set for [CAL] and the scale returns to the weighing mode.


When executing "span calibration", see "Span Calibration and Adjustment"

► Page 60

When executing a "calibration check", see "Calibration Check"

► Page 64

When "span calibration using the external weight" has been selected



4. Calibration

Span Calibration and Adjustment

Adjust to achieve correct scale sensitivity using either the internal weight (9436 only) or the external weight. Set the relevant "span calibration" in **CAL** in advance by following the procedure in "Before Starting Calibration ...".

(As the default setting, "span calibration using the internal weight" is set for 9436, and "span calibration using the external weight" is set for 9435.)

Saving the desired calibration
see "Before Starting Calibration"

► Page 58

- Span calibration using the internal weight (9436 series only) **I.CAL**

1 Press **CAL**

Span calibration using the internal weight will start automatically


INFO

IF "WAIT" IS DISPLAYED ...

The calibration record is being output. When output has finished, span calibration will start automatically.

INFO

IF "BUSY" IS DISPLAYED ...

There is something placed on the pan.
When this item is taken off the pan, the span calibration will start automatically. To cancel the span calibration, press .

INFO

IF "ERR H" IS DISPLAYED ...


See "Responding to Messages"
► Page 153

INFO



IF "ERR C" IS DISPLAYED ...

Span calibration was not completed for one of the following reasons.


- There is too large a discrepancy between the zero point of the scale and the sensitivity.
- A container has been placed on the pan.
- The pan is not on the scale.
- There is too large a discrepancy in the value of the internal weight.

Press  and redo the operation from the beginning. If even on doing this the same display reappears, calibrate the internal weight.

► Page 64



This may not be displayed.



4. Calibration

Span Calibration and Adjustment

"END" will be displayed and the scale will return to the weighing mode.

CAUTION



Prohibitions

**If calibration doesn't end normally and the scale stops,
do not move it nor leave it as it is.**

Moving the scale in such a condition may cause failure because the internal weight is not held correctly. Before moving the scale, be sure to turn the power on and start it up correctly (so that the internal weight is correctly held).


4

CALIBRATION

► Span calibration using the external weight **E.CAL**

1

Press  in the weighing mode.

When the GLP output function has been set to ON, initially the indication "WAIT" is displayed, then the scale model name and other information is output. After a little while  (the weight symbol) lights up and the weight value of the weight to be placed on the pan flashes.



GLP Output Function

► Page 158


INFO

IF "WAIT" IS DISPLAYED ...

The calibration record is being output. When output has finished, span calibration will start automatically.



INFO

IF "BUSY" IS DISPLAYED ...

There is something placed on the pan. Take the item off the pan and follow the procedure below. To cancel scan calibration, press . This message will not be shown at the 9434 series. Make sure that there is no object on the sample pan and perform calibration.

INFO

IF NO OPERATION IS PERFORMED WITHIN 60 SECONDS ...

"ERR C" (calibration error) is displayed. Press  ( with the 9434 series) and repeat the operation from the beginning.

4. Calibration

Span Calibration and Adjustment

2 Enter the calibration weight value.

If necessary change the weight value displayed to match the weight that will be used for calibration. If there is no need to change it, proceed to step 3.



(Enter a weight value if necessary.)



"Entering Numerical Values",

► Page 51

For details on the range of weight values that can be used, see "Specifications"

► Page 161



With models that don't feature the windbreak


3 Place the calibration weight on the pan.

Wait until the flashing weight value display changes to a flashing zero.



4 Take the calibration weight off the pan.

"END" will be displayed and the scale will return to the weighing mode.



INFO

IF "ERR C" IS DISPLAYED ...

Calibration has failed for one of the reasons given below.

- There is too large a discrepancy between the zero point of the scale and the sensitivity.
 - A container has been placed on the pan.
 - The pan is not on the scale.
 - The wrong weight has been placed on the pan.
 - No operation has been performed within 60 seconds of the flashing weight value or zero display.
- Press (with the 9434 series) and repeat the operation from the beginning.

4. Calibration

Span Calibration and Adjustment

With models that feature the windbreak

3 Place the weight on the pan.

Open the glass door in the windbreak, place the weight on the pan, and shut the glass door again. Wait until the flashing weight value display changes to a flashing zero.



4

CALIBRATION


INFO

SHUT THE GLASS DOOR FULLY.

After placing a weight on the pan or removing a weight from the pan, check that the glass door is fully shut.

4 Take the calibration weight off the pan.

Open the glass door in the windbreak, remove the weight from the pan and shut the glass door again. "END" will be displayed and the scale will return to the weighing mode.



INFO

AVOID DOING THE FOLLOWING:

- ▶ Putting your hand inside the glass door of the windbreak
- ▶ Touching the container or sample with bare hands
- ▶ Weighing samples (items to be weighed) of different temperatures

The heat will lead to convection, and this may make the scale display unstable. You are recommended to use forceps or gloves to carry containers and samples.

When dealing with samples (items to be weighed) at different temperatures, eliminate the temperature difference by leaving the samples around the pan inside the glass door before weighing.

4. Calibration

Calibration Check

This means checking for drift in the sensitivity of the scale by using the internal weight (9436 only) or the external weight. Set "calibration check" for **CAL** in advance by following the procedure in "Before Starting Calibration ...". (As the default setting, "span calibration" is set.)

Saving the desired calibration
see "Before Starting Calibration"

▶ Page 58

▶ Calibration check using the internal weight (9436 series only) **I.TEST**

1 Press **CAL**

A calibration check using the internal weight will start automatically, and the sensitivity drift will be displayed.


IF "WAIT" IS DISPLAYED ...

INFO

The calibration record is being output.
When output has finished, span calibration will start automatically.



IF "BUSY" IS DISPLAYED ...

INFO

There is something placed on the pan.
When this item is taken off the pan, the calibration check will start automatically.
To cancel the calibration check, press .

IF THERE IS NO NEED TO CHANGE THE SENSITIVITY DRIFT ...

INFO

On pressing  ( with the 9434 series) "ABORT" is displayed and calibration check ends. "What is sensitivity drift?"


▶ Page 68

IF "ERR H" IS DISPLAYED ...

INFO

See "Responding to Messages"

▶ Page 153



4. Calibration


Calibration Check

INFO

IF "ERR C" IS DISPLAYED ...

The calibration check has failed for one of the reasons given below.

- ▶ There is too large a discrepancy between the zero point of the scale and the sensitivity.
- ▶ A container has been placed on the pan.
- ▶ The pan is not on the scale.
- ▶ There is too large a discrepancy in the value of the internal weight.


Press  and redo the operation from the beginning. If even on doing this the same display reappears, calibrate the internal weight.

▶ Page 69

2

Press 

"END" will be displayed. The sensitivity drift is adjusted and the scale will return to the weighing mode.



CAUTION

**Prohibitions**

If calibration doesn't end normally and the scale stops, do not move it nor leave it as it is.

Moving the scale in such a condition may cause failure because the internal weight is not held correctly. Before moving the scale, be sure to turn the power on and start it up correctly (so that the internal weight is correctly held).

4. Calibration

Calibration Check


► Calibration check using the external weight **E.TEST**

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU:
Model with EC Type Approval

1

Press **CAL** in the weighing mode.

 (the weight symbol) will light up and the value of the weight that should be placed on the pan will flash.




INFO

IF "WAIT" IS DISPLAYED ...

The calibration record is being output.
When output has finished, span calibration will start automatically.



INFO

IF "BUSY" IS DISPLAYED ...

There is something placed on the pan. Take the item off the pan and follow the procedure below. To cancel calibration check, press  (with the 9434 series).

INFO

IF NO OPERATION IS PERFORMED WITHIN 60 SECONDS ...

"ERR C" (calibration error) is displayed.
Press   (with the 9434 series) and repeat the operation from the beginning.

4. Calibration

Calibration Check

2 Enter the calibration weight value.

If necessary change the weight value displayed to match the weight that will be used for calibration. If there is no need to change it, proceed to step 3.



(Enter a weight value if necessary.)



"Entering Numerical Values"

► Page 51

For details on the range of weight values that can be used, see "Specifications"

► Page 161



3 Place the calibration weight on the pan.

Wait until the flashing weight value display changes to a flashing zero.



4

CALIBRATION

INFO

WITH MODELS THAT FEATURE THE WINDBREAK ...

After placing a weight on the pan or removing a weight from the pan, check that the glass door is fully shut.

INFO

IF "ERR C" IS DISPLAYED ...

Calibration check has failed for one of the reasons given below.

- There is too large a discrepancy between the zero point of the scale and the sensitivity.
- A container has been placed on the pan.
- The pan is not on the scale.
- The wrong weight has been placed on the pan.
- No operation has been performed within 60 seconds of the flashing weight value or zero display.

Press (with the 9434 series) "ABORT" is displayed and calibration check ends.

4. Calibration

Calibration Check

4 Take the calibration weight off the pan.

The sensitivity drift is displayed.




INFO

IF THERE IS NO NEED TO CHANGE THE SENSITIVITY DRIFT ...

On pressing () with the 9434 series) "ABORT" is displayed and calibration check ends.

5 Press

"END" will be displayed. The sensitivity drift is adjusted and the scale will return to the weighing mode.



INFO

WHAT IS SENSITIVITY DRIFT?

The sensitivity drift is the amount by which the scale weight reading is off the true value when a weight close to the weighing capacity is placed on the pan.

For example, with the 9435 (weighing capacity of 320 g, minimum display digit of 0.001 g), if a 300 g weight is placed on the pan after a drift of "-0.005 g" has been indicated, the weight reading will be "299.995 g".

To correct sensitivity drift by adjustment, perform "span calibration"

► Page 60

4. Calibration

Calibration of the Internal Weight (9436 Only)

In the 9436 series, the weight for calibration is built in. The internal weight itself is calibrated on shipment from the factory, but it is possible to recalibrate it using external weights. This is called **P.CAL**

For the range of values for the external weights that can be used, refer to "Specifications"

► Page 161

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU:
Model with EC Type Approval

1

Press **CAL** for about 3 seconds.

This opens the calibration menu.

2

Select calibration of the internal weight.



3

Enter the administrator's password.

"Entering Numerical Values"

► Page 51

"Changing the Password"

► Page 157



4

Press **ENTER**

The password is acknowledged and the reference weight value for calibration flashes.



INFO

IF "WAIT" IS DISPLAYED ...

The calibration record is being output.
When output has finished, span calibration
will start automatically.

If the password is wrong ...

The error message shown to the right will be displayed and the display will return to the indication in step 1.



4. Calibration

Calibration of the Internal Weight (9436 Only)

5 If necessary, enter a weight value.

If no change is to be made, proceed to step 6 without doing anything.



(If necessary, enter a weight value.)



"Entering Numerical Values"

► Page 51

For the range of weight values that can be used, refer to "Specifications"

► Page 161



6 Place the weight on the pan.

Wait until the flashing weight value indication changes to a flashing zero indication.




INFO

IF "ERR C" IS DISPLAYED ...

The internal weight has not been calibrated for one of the following reasons.

- The wrong weight has been placed on the pan.
- No operation has been performed within 60 seconds of the flashing weight value or zero display.

Press  and repeat the operation from the beginning.

4. Calibration

Calibration of the Internal Weight (9436 Only)


7

Take the calibration weight off the pan.

Open the glass door of the windbreak, take the weight off the pan, and close the glass door.

INFO

IF "BUSY" IS DISPLAYED ...

There is something placed on the pan. When this item is taken off the pan, internal weight calibration will start automatically. To cancel internal weight calibration, press .

INFO

If "ERR H" is displayed ...

See "Responding to Messages"


► Page 153

INFO

IF "ERR C" IS DISPLAYED ...

The internal weight has not been calibrated for one of the following reasons.


- There is too large a discrepancy between the zero point of the scale and the sensitivity.
- A container has been placed on the pan.
- The pan is not on the scale.
- There is too large a discrepancy in the value of the internal weight.

Press  and repeat the operation from the beginning.

"END" is displayed, then span calibration using the internal weight starts. When span calibration using the internal weight ends, the scale returns to the weighing mode.

 P.CAL 3

 P.CAL 2

 P.CAL 1

 P.CAL 0

 WAIT

This may not be displayed.

 END

"Span Calibration and Adjustment"

► Page 60

4

CALIBRATION

CAUTION



Prohibitions

If calibration doesn't end normally and the scale stops, do not move it nor leave it as it is.

Moving the scale in such a condition may cause failure because the internal weight is not held correctly. Before moving the scale, be sure to turn the power on and start it up correctly (so that the internal weight is correctly held).


4. Calibration

Leaving a Record of Calibration

You can leave a record of execution of calibration and set an ID for a scale to facilitate management of multiple scales.

■ Example Printout of a Calibration Record

You can output a record of execution of calibration to a PC or printer (option). The WindowsDirect communication function (► Page 122) is useful for output to a PC. The output calibration record includes the following items.



Example printout from printer
(When the GLP output function is set to ON)

INFO

OUTPUTTING THE DATE AND TIME

Since the 9434/9435/9436 series doesn't incorporate a clock function, it is not possible to output the date and time from the scale.

4. Calibration

Leaving a Record of Calibration

■ Setting Output of a Calibration Record

Output of the calibration record can be set by turning the GLP output function ON and OFF.

GLP Output Function
▶ Page 158

1 Press for about 3 seconds.

This opens the calibration menu.

2 Select the GLP output function.



Stability Mark	GLP Output Function
----------------	---------------------


Lit	ON
Unlit	OFF

INFO

9434-SERIES ...


The menu for the GLP data output will be shown like this:

3 Change the setting.



Pressing  alternately sets the ON and OFF settings.



4 Return to the weighing mode.

Press  for about 3 seconds.

Check the presence or absence of the stability mark.



When ON is set the stability mark is lit.

4. Calibration

Leaving a Record of Calibration


■ Setting a Scale ID

When managing multiple scales, you can set a four-digit management number(ID) for each scale which will be indicated as part of calibration records output.


1 Press in the weighing mode.

This opens the main menu.

2 Select setting of a scale ID.



3 Enter the required numerals (max. 4 digits).




"Entering Numerical Values"

► Page 51

The default ID is "0000".



4 Return to the weighing mode.



Memo

5. Functions Relating to Taring

Zero Tracking Function

The 9434/9435 series has the following functions relating to the zero point and taring. Make use of these functions in accordance with the weighing environment and the application.

Zero / Taring Functions

Zero tracking function

Fluctuations in the zero point that occur immediately after turning the power ON and as a result of temperature changes are compensated for, so the zero indication is maintained.

► Page 76

Auto zero function

Drift of the zero point that occurs as a result of material left on the pan after measurement is automatically compensated for. See hint as below


► Page 78

Auto tare function

After outputting a weight reading, taring is executed automatically.

► Page 80

Zero / tare timing change function

After waiting for  (the stability mark) to light up, zero point setting / taring is executed. See hint as below

► Page 81



What is taring?

This is a function whereby the weight of the container placed on the pan is subtracted to set the display to zero, so that only the weight of the sample placed inside the container is indicated.



What is the zero point?

This means the state where nothing is placed on the pan, zero is indicated, and weighing can be started.


INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval.

5. Functions Relating to Taring

Zero Tracking Function


When the zero tracking function is set, when the indication is zero (including when taring is performed) the fluctuations in the zero point that occur immediately after turning the power ON and due to temperature changes and other factors are compensated for and the zero indication is maintained. (In the default setting the zero tracking function is ON.)

- 1** Check  (the zero tracking symbol) in the weighing mode.

Zero Tracking Symbol Zero Tracking Function

Lit	ON
Unlit	OFF

If you proceed to the next step while zero tracking is ON, it goes OFF.




- 2** Press .


This opens the main menu.

SETTING FROM THE ZERO / TARING MENU


INFO

You can also press  for about 3 seconds and make the setting from the zero / taring menu.


- 3** Select the zero tracking function.




- 4** Confirm the ON or OFF selection.

The ON or OFF status will be selected and the scale will automatically return to the weighing mode. After setting "ON",  (the zero tracking symbol) lights up.

When the setting has been made from the zero / taring menu

Press  for about 3 seconds.



5. Functions Relating to Taring

Auto Zero Function

When the auto zero function is set, any drift of the zero point that occurs as a result of material left on the pan after weighing is automatically compensated for so that zero is displayed. Note that the auto zero function cannot be used in combination with formulation.

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

1 Press **←0/T←** for about 3 seconds in the weighing mode.


This opens the zero / taring menu.

2 Select the auto zero function.



[A.ZERO]

Check the presence or absence of the stability mark.



What is the current situation?

Stability Mark

Auto Zero Function

Lit

ID is ON

Unlit

ID is OFF

What do you want to do?

To set or Update ...

To Cancel ...

→ Press **←5→** and got to step 3.

Press **MENU ENTER** and got to step 4.

→ Press **MENU ENTER** and got to step 3.

Go to step 4.

3 Enter the value for the range for automatic compensation to the zero point (auto zero range).


(Enter the zero range value.) → **MENU ENTER** [SET]



"Entering Numerical Values"

▶ Page 51

If there is anything with a weight lower than or equal to the auto zero range value left on the pan after weighing the sample, it will automatically be compensated for and the zero point will be established when **→** (the stability mark) lights up.



When ON is set the stability mark is lit.

5. Functions Relating to Taring

Auto Zero Function

INFO


AUTO ZERO RANGE VALUE

The auto zero range value is only effective in the units that are displayed when the value is entered. If other units are later selected, change (update) the setting for the zero range value by following the procedure from step 1 while these new units are displayed. The upper limit value for the zero range is 99 d. 1 d is the minimum indication in the displayed units. For example, for a scale with a minimum indication of 0.001 g, the situation is as follows.

Units	Minimum Indication	Upper Limit Value for the Zero Range
g	0.001 g	0.099 g
ct	0.01 ct	0.99 ct

4

Return to the weighing mode.

Press  for about 3 seconds.

5

FUNCTIONS RELATING TO TARING

5. Functions Relating to Taring

Auto Tare Function


When the auto tare function is set, the scale is automatically tared after the weight reading has been output, and the indication at that point is set to zero.

- 1** Press **→0/T←** for about 3 seconds in the weighing mode.

This opens the zero / taring menu.

- 2** Select the auto tare function.

<div>UNIT ▲ [A.TARE] ▼ FUNC</div>	
Stability Mark	Auto Tare Function
Lit	ON
Unlit	OFF





- 3** Change the setting.

Pressing **MENU/ENTER** alternately sets the ON and OFF settings.



- 4** Return to the weighing mode.



5. Functions Relating to Taring

Zero / Tare Timing Change Function

The zero / tare timing change function allows you to select whether setting of the zero point / taring is ➡ (the stability mark) to light up, or after waiting for ➡ (the stability mark) to light up after pressing **←0/T←**. This function can also be applied to operations under the auto zero function and the auto tare function. (The default setting is for execution without waiting for ➡ (the stability mark) to light up.)


INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

1 Press **←0/T←** for about 3 seconds in the weighing mode.

This opens the zero / taring menu.

2 Select the zero / tare timing change function.



Stability Mark

Zero / Tare Timing Change Function

Lit

The scale doesn't wait for stability

Unlit

The scale waits for stability.



3 Change the setting.

Pressing **MENU/ENTER** alternately selects the "wait for stability" and "don't wait for stability" settings.



4 Return to the weighing mode.

Press **RL←** for about 3 seconds.



6. Adjusting Response and Stability

Selecting the Weighing Mode

The response and stability of the scale can be adjusted in several ways in accordance with the installation environment (degree of vibration and so on) and the weighing application (whether solid objects / clumps or poured liquids / powders are being weighed).

- ▶ **Stability:** The degree to which the weight reading is stable, with little fluctuation
- ▶ **Response:** The speed of the reaction to changes in the weight on the pan

Set the optimum conditions for your application by following the procedure below.

Selecting the weighing mode

The 9434/9435/9436 series offers two basic weighing modes. Select the right one in advance in accordance with the environment of use and the application.



General weighing mode

This is the fundamental mode in which response and stability are given equal emphasis.

▶ Page 83



Pouring mode

This is a weighing mode where response is given priority over stability, which is suited to operations where substances like liquids or powders are poured out until a target weight is reached.

▶ Page 83



Adjusting the response and stability in real time

The ratio of response to stability and stability can be changed in stages by pressing  and .

"Easy Setting of Response and Stability" ▶ Page 84

Adjusting ➡ (the stability mark)

The conditions for making ➡ (the stability mark) light up (the stability detection range and the stability mark lighting timing) can be adjusted.

"Adjusting the Stability Mark" ▶ Page 85

6. Adjusting Response and Stability

Selecting the Weighing Mode

9434/9435/9436 series scales have the following two types of weighing mode.
Set the right mode in advance depending on the environment of use and the weighing application.

■ Selecting the General Weighing Mode

This is the fundamental mode in which response and stability are given equal emphasis.


1 Press in the weighing mode.

This opens the main menu.

2 Select the general weighing mode.



The scale has been set in the general weighing mode.



■ Selecting the Pouring Mode


This is the weighing mode suited to pouring out a sample (substance being weighed such as a powder or liquid) until a target weight is reached.
The update of the display is fast and the final value can be stabilized for reading.


1 Press in the weighing mode.

This opens the main menu.

2 Select the pouring mode.



The pouring mode is established and  (the pouring symbol) lights up.




6. Adjusting Response and Stability

Easy Setting of Response and Stability

During weighing, the response and stability of the weighing mode can be adjusted in stages in accordance with the installation environment and the weighing application. The 9434/9435/9436 series scales feature excellent response and stability, but since response and stability are generally antagonistic, if one is prioritized it will to some extent weaken the characteristics of the other.


Easy Setting allows quick adjustment to match your preference, requirements or particular application.

Easy setting indicator




Priority Given to Response ↔ **Priority Given to Stability**

Easy setting indicator

Press  **Operation**

The more times you press this key, the further ▼ (the level indicator) moves to the R side, increasing the response of the display in stages.

Press  **Operation**

The more times you press this key, the further ▼ (the level indicator) moves to the S side, increasing the stability of the display in stages.

For these circumstances ...

- ▶ When you want to weigh things quickly
- ▶ When you want to improve working efficiency
- ▶ When weighing out target quantities of a liquid or powder or when making a formulation

- ▶ When you want to weigh things with confirmed accuracy
- ▶ When the display is unstable
- ▶ When the scale is used in a location where there is a constant and relatively large vibration
- ▶ When the scale is subject to constant air movements and the indication wavers

6. Adjusting Response and Stability

Adjusting the Stability Mark

The stability mark is a symbol (➡) that is displayed when it is determined that the weight reading has stabilized.

The following settings adjust conditions for lighting up of ➡ (the stability mark).

- ▶ Stability detection range
- ▶ Stability mark lighting timing

Normally there is no need to change these settings. (Change the settings if, for example, you want to relax the conditions and make ➡ (the stability mark) light more easily because the environment is unstable, or to speed up operation if stability is used to automatically print or output data.

■ Setting the Stability Detection Range

The stability detection range is a value set as a count of the smallest digit that is displayed, and the display is judged to be stable if fluctuation in the weight reading is within this count during a fixed time.

(The default setting for the stability detection range is 1 count (1d).)

INFO

LIGHTING UP OF ➡ (THE STABILITY MARK)

The lighting up of ➡ (the stability mark) indicates the fact that the weight reading is stable.
If the load is being changed slowly, or due to the settings relating to stability detection, the weight reading may change while ➡ (the stability mark) remains lit, or ➡ (the stability mark) may light temporarily and then the weight reading may change.

Effect of reducing the stability detection range

It takes some time for ➡ (the stability mark) to light up, but after it has lit the weight reading is stable (improvement in reliability).

Effect of increasing the stability detection range

➡ (the stability mark) can be made to light more quickly but the weight reading is liable to fluctuate after it has lit (improvement of weighing and data output speeds).


1

Press  in the weighing mode.

This opens the main menu.

2


Select setting of the stability detection range.



6. Adjusting Response and Stability

Adjusting the Stability Mark

3 Select the value for the stability detection range.



Select the stability detection range from among the following options depending on the weighing application and purpose: 0.5d, 1d, 10d, 50d*1, 100d*1, 1000d*1.

*1: Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

4 Confirm and return to the weighing mode.


The stability detection range has now been set.



INFO

IF DATA OUTPUT IS SLOW ...

There are factors in the installation environment and the sample that make the display unstable. If data output triggered by stability detection is very slow, increase the stability detection range.



■ Setting the Stability Mark Lighting Timing

The timing according to which ➡ (the stability mark) lights can be set in accordance with the application and required accuracy.

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

Effect of speeding up the timing for lighting up of the stability mark

At the same time as stability is detected, ➡ (the stability mark) lights up. The weight reading after ➡ (the stability mark) lights up becomes more susceptible to fluctuation since many samples can be weighed in succession and the working time can be used more efficiently (improvement of weighing speed).

Effect of setting the stability mark lighting timing to the standard setting

When stability is detected and remains detected for a fixed time, ➡ (the stability mark) lights up. ➡ (the stability mark) lighting judgments become stricter and the weight reading is stable after it has lit, so highly accurate weighing is possible (improvement of reliability of data).


6. Adjusting Response and Stability

Adjusting the Stability Mark


1 Press in the weighing mode.


This opens the main menu.

2 Select setting of (the stability mark) lighting timing.




3 Check the lighting timing setting.

 [FAST]	
Stability Mark	Stability Mark Lighting Timing
Lit	Fast
Unlit	Standard





4 Change (the stability mark) lighting timing.

Pressing  alternately sets the "fast" and "standard" settings.




5 Return to the weighing mode.

Press  for about 3 seconds.



7. Setting Units

Selecting Units to Display

9434/9435/9436 series scales can be made to indicate weights in units other than the basic units of grams by switching units with the  key in the weighing mode. You must register the units you will require in advance.

On shipment from the factory, the only unit registered is g (grams).

"Switching Units"

► Page 84

■ Units That Can Be Displayed and Conversion Factors

Some of the units below cannot be selected in some countries due to legal restrictions.

Weight Unit (Weight Name)	Gram Conversion ^{*1}	Conversion Factor ^{*2}
g (gram)	1	1
mg (milligram) ^{*3, *7}	0.001	1000
kg (kilogram)	1000	0.001
ct (carat) ^{*4}	0.2	5
mom (momme) ^{*7}	3.75	0.2666667
lb (pound) ^{*7}	453.592	0.00220462
oz (ounce) ^{*7}	28.34955	0.035274
ozt (troy ounce) ^{*7}	31.1035	0.0321507
dwt (pennyweight) ^{*7}	1.55517	0.643015
GN (grain) ^{*7}	0.064799	15.4324
HTI (Hong Kong tael) ^{*7}	37.429	0.0267173
STI (Singapore Ttael) ^{*7}	37.79936	0.0264554
TTI (Taiwan tael) ^{*5, *7}	37.5	0.0266667
MTI (Malaysian Ttael) ^{*7}	37.79289	0.0264600
m (mesghal) ^{*7}	4.6083	0.216999
o (parts pound) ^{*7}	0.88592	1.12877
B (baht) ^{*7}	15.2	0.0657895
S (sawaran) ^{*7}	7.999	0.1250156
Ks (kyats) ^{*7}	16.606	0.0602191
T (tola) ^{*7}	11.664	0.0857339
User ^{*6, *7}		Can be set as required by the user ^{*6}

^{*1} If we take the value in the Gram conversion column to be "a", the formula is as follows. "a" × scale weight reading (each unit) = value in gram units

^{*2} If we take the conversion factor to be "k", the formula is as follows. "k" × value in gram units = scale weight value (selected units)

^{*3} mg cannot be selected on models whose minimum indication is 10 mg or greater.

^{*4} The minimum indication for ct (carat) may vary depending on the production lot even if they are the same model.

^{*5} There are five kinds of Taiwan tael (TTI-1 to TTI-4). The conversion factor is the same, but the minimum indication is as follows.

TTI-1 A value 5 times that of TTI-2
TTI-2 The minimum value
TTI-3 A value twice that of TTI-2
TTI-4 A value 10 times that of TTI-2

^{*6} With user-specified units, the conversion factor (*2) and minimum indication can be set as required. For details on the method for setting user-specified units, see "Setting User-Specified Units" (► Page 86).

^{*7} Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

7. Setting Units

Selecting Units to Display

Select and set the units you require to display so that they can be called up by pressing **UNIT** during weighing operation.


For details on user-specified units, see **"Setting User-Specified Unit"**

► Page 90


- 1 Press **UNIT** for about 3 seconds in the weighing mode.

This opens the unit setting menu.

- 2 Select the units to be called up and check if **→** (the stability mark) is displayed or not.



Stability Mark	Registering Units
Lit	ON
Unlit	OFF




- 3 Change the setting for units.


Pressing **MENU/ENTER** alternately sets the ON and OFF settings.



To set or cancel other units, go to step 2.
To quit, go to step 4.



- 4 Return to the weighing mode.



- 5 Press **UNIT** to call up selected units.

"Switching Units", ► Page 43

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

7. Setting Units

Setting User-Specified Units

■ Conversion Factors

Numerical values (multipliers) by which the weight reading (in grams) is multiplied can be set without restriction.

1 Press for about 3 seconds in the weighing mode.

This opens the unit setting menu.

2 Select the user-specified units.






Check the presence or absence of the stability mark.



What is the current situation?

What do you want to do?

Stability Mark	User-Specified Units		To Set / Update	To Cancel
Lit	SET	→	Press  and go to step 3.	Press  and go to step 5.
Unlit	Cancelled	→	 and go to step 3.	Go to step 5.


3 Select setting of the conversion factor.



7. Setting Units

Setting User-Specified Units

4 Enter the conversion factor.

(Enter the conversion factor.) →  [SET]

INFO

CHANGING THE POSITION OF THE DECIMAL POINT

When entering a conversion factor, the position of the decimal point can be changed (▶ Page 91).

INFO

CALCULATION FORMULA FOR THE CONVERSION FACTOR


If we take the conversion factor to be "k" the formula is as follows.
 $\text{"k"} \times \text{value in gram units} = \text{scale weight reading (user-specified units)}$



"Entering Numerical Values",

▶ Page 51

5 Return to the weighing mode.

Press  for about 3 seconds.

6 Press to call up the user-specified units.



When user-specified units are called up, no indication of units is given.

"Switching Units",

▶ Page 43

7. Setting Units


Setting User-Specified Units

■ Minimum Indication

You can set the minimum weight reading for the user-specified units.
Make the setting by replacing steps 3 and 4 of the conversion factor procedure
(▶ Page 90) with the following procedure.


3

Select setting of the minimum indication.



4

Enter the minimum indication.

(Enter the smallest indication.) →  [SET]



"Entering Numerical Values"

▶ Page 51

INFO

ABOUT THE MINIMUM WEIGHT READING FOR USER-SPECIFIED UNITS ...

This can be set to any required value but in some cases it will not be possible to guarantee the stability of the weight reading display.

Memo

8. Application Function Mode

Application Function Mode

Application Function Mode

You can choose one of the three modes indicated below to suit the application.

PIECE COUNTING

You can set the unit weight of the sample (item to be weighed) and then "count" the number of pieces present.

► Page 95

PERCENTAGE WEIGHING

You can measure weights as a percentage of a reference weight.

► Page 100

FORMULATION

This mode is convenient when mixing a number of different samples together according to a formula.

► Page 105

WHEN THE APPLICATION FUNCTION MODE IS SET ...

- Press alternately selects the weighing mode (gram or other unit indication) and the application function mode in use.
- It can be used in combination with the comparator function (► Page 110)
- If the power is turned OFF and back ON the scale will start up in the weighing mode but the application function mode settings will be retained.
- Pressing displays the menu for setting the various application function modes. If you then press or , the top hierarchical level of the main menu appears. The flow of the operation for displaying the menu is shown below.

INFO

Piece counting

Unit weight setting menu

Percentage weighing

Percentage reference value setting menu

Formulation

Component number and gross weight setting menu

Press or

Displays the main menu.

8. Application Function Mode

Counting Pieces by Weight (Piece Counting)

You can set the unit weight (weight of a single piece) of the item in advance and then display the number of pieces in the sample.

The unit weight is recorded by placing a sample on the pan that comprises the "number of pieces used for setting".

Unit weights for up to five different types of items can be set at the same time.


POINTS WHERE CARE IS NECESSARY

INFO

- ▶ If the sample is spread out too much or unevenly in the container on the pan, accurate piece counting will not be possible.
- ▶ If a large quantity sample is to be weighed, and the quantity in the sample greatly exceeds the quantity used to set the unit weight, there may be a large counting error.

TO MINIMIZE THE COUNTING ERROR ...

INFO

- ▶ In step 5 of "Preparation for Piece Counting", make the number of pieces used for setting the unit weight as large as possible.
- ▶ When actually measuring numbers of pieces, don't place a large quantity of the sample on the pan at one time but rather add a small portion at a time and, when the display has stabilized, press , for at least 3 seconds to update the unit weight. Keep repeating this operation.


■ Preparation for Piece Counting (Including Setting the Unit Weight)

The preparations for piece counting are explained here.

Only make the setting in the following circumstances.

- ▶ You are performing piece counting for the first time.
- ▶ You are switching from another application function mode to piece counting.


1

Press  in the weighing mode.

This opens the main menu.

2

Select piece counting.



8. Application Function Mode

Counting Pieces by Weight (Piece Counting)

3 Select the item number.

[SAMPLE] →  (Item number: select from

1 2 3 4 5) →  [SET]

Five different unit weight settings
(**1 2 3 4 5**) can be recorded.




4 Check the number of pieces indication.

The display will indicate whether a unit weight has already been set.

When no unit weight has been set for the item number:

[---]





When a unit weight has already been set for the item number:

(The number of pieces is indicated.)



- ▶ To update the unit weight, ▶ proceed to step 5.
- ▶ If you are not intending to update the unit weight, the procedure from step 5 on is unnecessary. You can start piece counting right away. "Counting Numbers of Pieces", ▶ Page 97

5 Select the number of pieces used for setting.

 →  (Select the number of pieces used for setting.)



NUMBER OF PIECES USED FOR SETTING

INFO



The number of pieces used for setting can be selected from among 5 pieces, 10 pieces X pieces. In order to minimize counting error, make the number of pieces used for setting the unit weight as large as possible.

8. Application Function Mode

Counting Pieces by Weight (Piece Counting)

INFO

ON PRESSING  OR  ...

A menu option other than the number of pieces for setting may be displayed but this is not abnormal. Press  or  several times to return to the number of pieces for setting display.

6


Place the container on the pan and press 

The scale will be tared.

7

Put a quantity of the item to be counted corresponding to the selected "number of pieces used for setting" into the container.

8

Check that  (the stability mark) lights up, then confirm.

 [SET]



The unit weight will be set and the number of pieces of the sample will be indicated. You can now start piece counting.

"Counting Numbers of Pieces", ► Page 97


If you wish to add the unit weight for another item to be counted, see "Changing a Unit Weight, or Adding a New Unit Weight",


► Page 99

■ Counting Numbers of Pieces

1

Enter the piece counting mode

If you have returned to the weighing mode (mode where grams or other units are displayed) from the piece counting mode, then press  to enter the counting mode.



INFO

IF THE PIECE COUNTING MODE IS NOT ESTABLISHED ...

The preparations for piece counting have not been completed. Make settings according to "Preparation for Piece Counting (Including Setting the Unit Weight)"

► Page 95


8


APPLICATION FUNCTION MODE

8. Application Function Mode

Counting Pieces by Weight (Piece Counting)

2 Select the item number.

Each time  is pressed for about three seconds, the selection moves to the next item number and the corresponding item number indication (from **1** to **5**) is displayed.



INFO

IF THE DISPLAY APPEARS AS SHOWN TO THE RIGHT ...

This means that the unit weight has not been set for the selected item number. To make this setting, follow the procedure in "Changing a Unit Weight, or Adding a New Unit Weight" (▶ Page 99).




3 Place a container on the pan and press


The scale will be tared.


4 Add the sample to be counted into the container.

The number of pieces in the sample is indicated.
The operations of each of the keys after setting are summarized below.

On pressing  ...


Establishes the unit weight setting menu.
(▶ step 3 onward on Page 99.)

On pressing  ...

Pressing this key alternately displays the set unit weight (in grams) and the number of pieces. Press  while the unit weight is displayed to output the unit weight. While the unit weight is displayed, * (the hold display symbol) is displayed.

On pressing  for about 3 seconds...

The unit weight is recalculated and updated.

On pressing  ...

The weighing mode is established.
Pressing the key once more returns you to the piece counting mode.


8. Application Function Mode

Counting Pieces by Weight (Piece Counting)

■ Changing a Unit Weight, or Adding a New Unit Weight


1 Establish the piece counting mode.

While the weighing mode (mode where grams or other units are displayed) is established, press **FUNC** to switch to the application function mode.



2 Select the item number whose unit weight you want to change, or for which you want to add a unit weight.

Each time you press **UNIT** for about 3 seconds, the next item number is displayed. "Counting Numbers of Pieces" ► Page 97



3 Press **MENU ENTER**

The number of pieces used for setting will be displayed.



4 Select the number of pieces used for setting.

UNIT (Select the number of pieces used for setting.)
FUNC



5 Place the container on the pan and press **→ 0/T ←**


The scale will be tared.

6 Put a quantity of the item to be counted corresponding to the selected "number of pieces used for setting" into the container.

7 Check that **→** (the stability mark) lights up, then confirm.

MENU ENTER → [SET]

The unit weight will be added, and piece counting will become possible.



8. Application Function Mode

Percentage Weighing

In this mode the weight of the sample is converted to a percentage of the reference weight. The following two setting methods are available for percentage weighing.


100% Reference	The reference weight is set as 100%.
Specific Percentage Reference	The reference weight is set as a percentage value of your choice.

■ Preparation for Percentage Weighing

1 Press in the weighing mode.

This opens the main menu.

2 Select percentage weighing.



The setting beyond this point differs depending on the percentage value you are assigning to the reference weight.

INFO

If the reference weight is being set as 100%, see

- ▶ "When setting the reference as 100% ..." (▶ Page 101).

If the reference weight is being set as a specific percentage, see

- ▶ "When setting the reference as a percentage of your choice ..." (▶ Page 102).

8. Application Function Mode

Percentage Weighing

When setting the reference as 100% ...

3 Select the 100% reference.



→ (Check the indication.)

The indication differs depending on whether a reference value has already been set or not.



When no percentage reference value has been set

[---]


When a percentage reference value has already been set

(The percentage reference value is displayed.)

- ▶ To update the percentage reference value,
 - ▶ proceed to step 4.
- ▶ If you are not updating the percentage reference value, the following steps are not necessary.
- ▶ "Weighing Percentages", ▶ Page 104



4 Select 100% reference setting.



5 Place the container on the pan and press → 0/T ←

The scale will be tared.

6 Place the sample that is to provide the reference weight in the container.

8. Application Function Mode

Percentage Weighing

7

Check that ➡ (the stability mark) lights up, then confirm.

MENU
ENTER → [SET]

A percentage value with the reference weight taken to be 100% is displayed. Percentage Weighing is now possible.

"Weighing Percentages", ► Page 104



INFO

WHAT TO DO IF ...

It is not possible to use a reference weight that weighs less than 100 times the minimum indication of the scale as the reference weight.

When setting the reference as a percentage of your choice ...

3

Select the specific percentage reference.

UNIT
▲
FUNC
▼
[SAMPLE] → MENU
ENTER [SET]

→ (Check the indication.)

The indication differs depending on whether a reference value has already been set or not.


When no percentage reference value has been set

[---]

When a percentage reference value has already been set

(The percentage reference value is displayed.)

- To update the percentage reference value,
 - proceed to step 4.
 - If you are not updating the percentage reference value, the following steps are not necessary.
- "Weighing Percentages", ► Page 104






8. Application Function Mode

Percentage Weighing

4 Enter a percentage value of your choice.

 → [OPT REF] →




 (Enter the percentage value.) → 




"Entering Numerical Values", ► Page 51


5 Place the container on the pan and press 

The scale will be tared.



6 Place the sample that is to provide the reference weight in the container.

7 Check that  (the stability mark) lights up, then confirm.


 → [SET]



A percentage value calculated by conversion on the basis that the reference weight is equal to the set percentage is displayed.

Percentage weighing is now possible.

"Weighing Percentages", ► Page 104



The specific percentage weighing symbol lights up.

8

APPLICATION FUNCTION MODE

INFO

WHAT TO DO IF ...


It is not possible to use a reference weight such that the weight corresponding to 100% is less than 100 times the minimum indication of the scale.


8. Application Function Mode

Percentage Weighing

■ Weighing Percentages

1 Establish the percentage weighing mode.

If you have returned to the weighing mode (mode where grams or other units are displayed) from the percentage weighing mode, then pressing  will take you back to the percentage weighing mode.



INFO

IF THE PERCENTAGE WEIGHING MODE IS NOT ESTABLISHED ...

The preparations for percentage weighing have not been completed. Make setting in accordance with "Preparation for Percentage Weighing" (▶ Page 100)


2 Place the container on the pan and press

The scale will be tared.

3 Insert the sample (item to be measured) into the container.



A percentage value obtained by conversion based on the set reference percentage value and reference weight is displayed.


The operations of each of the keys after setting are summarized below.

On pressing  ...


The percentage reference value setting menu is displayed.
(▶ step 4 onward on Pages 101 and 102)

On pressing  ...

The set reference weight (in grams) and the percentage indication are displayed alternately. Press  while the reference weight is displayed to output the reference weight. While the reference weight is displayed,  (the hold display symbol) is displayed.

On pressing  for about 3 seconds ...

The 100% reference and specific percentage value are displayed alternately.

On pressing  ...

The mode is switched to the weighing mode.
Pressing the key again will return you to the percentage weighing mode.

8. Application Function Mode

Formulation


This function is useful when mixing multiple components together by weight, according to a formula. Use this function while the printer is connected to a printer or PC. The weight of each component is measured and output or added, and on completion of the formulation the gross weight is output. During formulation the auto zero function (▶ Page 78) will not work.

■ Performing Formulation

1 Press **MENU/ENTER** in the weighing mode.

This opens the main menu.

2 Set the scale to the formulation mode.



The scale is now ready to weigh.
If necessary, set output of the component numbers and output of the gross weight.

- ▶ "Outputting Component Numbers", ▶ Page 108
- ▶ "Outputting the Gross Weight", ▶ Page 109

3 Place the container on the pan and press **→0/T←**

The scale will be tared.



4 Press **PRINT**

Formulation starts.

INFO

WHEN THE GLP OUTPUT FUNCTION (▶ PAGE 158) IS SET TO ON ...


The scale ID (▶ Page 158) and other information is printed.



8. Application Function Mode

Formulation


5 Insert the component into the container.



6 Press 

The weight value of the current sample (item to be weighed: element) is output / recorded and the scale is automatically tared.

Now repeat the operations in steps 5 and 6 to add the other components to the formulation.



The net weight symbol lights up.

7 On completion of formulation, press  ( with the 9434 series).

The total of the individual weight values up to this point (gross weight) is displayed and the scale returns to the ready to weigh status.



The gross weight symbol flashes.

INFO

ATO OUTPUT THE GROSS WEIGHT

Make the setting in "Outputting the Gross Weight" (▶ Page 102) in advance.

INFO

WHEN THE GLP OUTPUT FUNCTION (▶ PAGE 102) IS SET TO ON ...

The signature panel is printed after the total weight.




The ready symbol lights up, indicating that the scale is ready to weigh.

8. Application Function Mode

Formulation


The operation after setting is as follows.

When in the ready to weigh status:

On pressing  ...


The weighing mode is established.
Pressing the key once more returns you to the ready to weigh status.

When weighing is in progress:

On pressing  ...

The gross weight of the components weighed up to that point is displayed for about 2 seconds.

Example printout from printer
(When the GLP output function is set to ON)



8. Application Function Mode

Formulation

■ Outputting Component Numbers

The numbers for each component are automatically assigned to the output results.

1 Press in ready to weigh status while in the formulation mode.

This opens the main menu.

INFO

IF THE READY TO WEIGH STATUS IS NOT ESTABLISHED ...

Perform steps 1 and 2 of formulation (▶ Page 105)

2 Select component number output setting.




[ELM.NUM]

Stability Mark


Outputting Component Numbers


Lit ON


Unlit OFF




3 Change the output setting.

Pressing  alternately sets ON and OFF for the output setting.

 → [SET]



4 Return to ready to weigh status.

Press  for about 3 seconds.

Component number

Weight reading for each component (output regardless of the ON/OFF status of component number output)

FORMULATION MODE

CMP001=	17.628g
CMP002=	17.628g
CMP003=	17.681g
CMP004=	17.668g
CMP005=	17.659g
TOTAL=	88.264g

8. Application Function Mode

Formulation

■ Outputting the Gross Weight

The gross weight for a formulation weighing operation is output at the same time it is displayed. The gross weight is output together with the printed indication: "TOTAL =".

1 Press in ready to weigh status while in the formulation mode.

This opens the main menu.

INFO

IF THE READY TO WEIGH STATUS IS NOT ESTABLISHED ...

Perform steps 1 and 2 of formulation (▶ Page 105)

2 Select gross weight output setting.



[TOTAL]

Stability Mark


Outputting the Gross Weight

Lit


ON


Unlit


OFF




3 Change the output setting.


Press  alternately sets ON and OFF for the output setting.

 → [SET]



4 Return to ready to weigh status.

Press  for about 3 seconds.



9. Comparator Function

Comparator Function

The comparator function performs a comparison between the weight reading and a reference value or target value and displays the status of this comparison.

Comparator Function

You can select and use either of these modes according to the environment of use and application.



TARGET MODE

After setting a target value and a tolerance range with respect to that target value, excesses and deficits in relation to the target value are indicated by **HI**, **OK** and **LO** (the comparator symbols).

► Page 111

CHECKWEIGHING MODE

After setting the threshold values at the upper and lower limits of the pass range, when a sample is weighed a pass or fail determination is indicated by **HI**, **OK** and **LO** (the comparator symbols). An out of range determination is indicated by all comparator symbols OFF.

► Page 113

INFO

BEFORE SETTING THE COMPARATOR FUNCTION

- It can be used in combination with the application function mode (► Page 94)
- If you are already using the application function mode, read "When the application function mode is set ..." (► Page 94).
- The comparator function settings are retained even if the power is switched off.


9. Comparator Function

Target Mode

1 Press in the weighing mode.

This opens the main menu.




2 Select the target mode.



What is the current situation?

Stability Mark	Target Mode
Lit	ON
Unlit	OFF


What do you want to do?

To Set / Update	To Cancel
Press  and go to step 3.	Press  and go to step 4.
Press  and go to step 3.	Go to step 4.


3 Enter the target value and the tolerance range with respect to the target value.

"Entering Numerical Values", ► Page 51


When entering the target value:



When entering the tolerance range with respect to the target value:



4 Return to the weighing mode.

Press  for about 3 seconds.

9. Comparator Function

Target Mode

5

Place the container on the pan and press 

The scale will be tared.

6

Insert a sample into the container.

Excess or deficiency is determined according to the the following conditions.

The comparator symbols light in accordance with the excess/deficiency judgment.



Condition	Judgment	Comparator Symbol
Over the target value range	Large difference with respect to the target value	HI (flashes slowly)
	Small difference with respect to the target value	HI (flashes quickly)
Within the target value range (target value ± permissible range)	Acceptable	OK
Under the target value range	Small difference with respect to the target value	LO (flashes quickly)
	Large difference with respect to the target value	LO (flashes slowly)

9. Comparator Function

Checkweighing Mode


1 Press in the weighing mode.

This opens the main menu.

2 Select the checkweighing mode.



Check the presence or absence of the stability mark.






What is the current situation?

Stability Mark Checkweighing Mode

Lit	ON
Unlit	OFF

What do you want to do?

Einstellung/Aktualisierung Abbruch

Press  and go to step 3.	Press  and go to step 4.
Press  and go to step 3.	Go to step 4.


3 Enter the pass range upper limit value and lower limit value, and the checkweighing range lower limit value and checkweighing range upper limit value.


"Entering Numerical Values",

► Page 51

To enter the pass range upper limit value:





upper limit value.) →  [SET]



To enter the pass range lower limit value:



lower limit value.) →  [SET]




9

COMPARATOR FUNCTION



9. Comparator Function

Checkweighing Mode

To enter the checkweighing range lower limit value:



To enter the checkweighing range upper limit value:



BE SURE TO DOUBLE CHECK ALL VALUES.

INFO

If the entered values don't go together logically, for example if a value lower than the lower limit value is entered as the upper limit value, the values will be automatically corrected and other values will be set. Particular care is required when entering new values where settings have been made before (updating).

4

Return to the weighing mode.

Press **RL** for about 3 seconds.

5

Place the container on the pan and press \rightarrow O / T \leftarrow


The scale will be tared

6

Insert the sample (item to be measured) into the container.

Pass or fail determination is based on the following conditions.

The comparator symbols light in accordance with the pass or fail determination.



9. Comparator Function

Checkweighing Mode

Condition	Result	Comparator Symbol
Upper limit value of the checkweighing range < indication	Out of Range	All off
Upper limit value of the pass range < indication ≤ upper limit value of the checkweighing range	HI	HI
Lower limit value of the pass range ≤ indication ≤ upper limit value of the pass range	PASS	OK
Lower limit value of the checkweighing range ≤ indication < lower limit value of the pass range	LO	LO
indication < lower limit value of the checkweighing range	Out of Range	All off


Memo

10. Connection & Communication with Peripheral Devices


Convenient Functions Relating to Output
















With 9434/9435/9436 series scales, weight readings, settings and other data can be output to a personal computer or a printer. This section describes some convenient functions relating to output, and how to connect the scale to a PC or printer (option).

INFO

Using a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval, when the weight value is unstable  Communication symbol blinks with no weight data output, when the weight value becomes stable this symbol lits with weight data output.

■ Printing / Outputting Automatically (Auto Print Function)

This function allows you to automatically output the displayed weight reading at each weighing without pressing . Select the output timing from among the following five modes.

	Stable Positive Value	Stable Negative Value	Stable Zero Indication	Pass in Checkweighing Mode	Explanation
Mode 1 					When stability is detected with a positive value, the value is output.
Mode 2 					When stability is detected with a positive or negative value, the value is output.
Mode 3 					When stability is detected with a positive value, or when the reading has returned to zero, the value is output.
Mode 4 					When stability is detected with a positive or negative value or when the reading has returned to zero, the value is output.
Mode 5 					When the auto print function is used in combination with the checkweighing mode ( Page 116) and stability is detected with an "OK" determination, the value is output.

: Output, Blank: Not output


10. Connection & Communication with Peripheral Devices

Convenient Functions Relating to Output

1 Press **PRINT** for about 3 seconds in the weighing mode.

This opens the output menu.

2 Select the auto print function.



What is the current situation?


Stability Mark	Auto Print Function
Lit	ON
Unlit	OFF

What do you want to do?


To Set / Update	To Cancel
Press UNIT and go to step 3.	Press MENU and go to step 5.
Press MENU and go to step 3.	Go to step 5.

3 Select the mode for output timing.

Select the output timing from among mode 1 to mode 5 (see the table on the previous Page).



As an example, assume here that mode 3 is selected (output with a stable positive value or a stable zero indication).




10

CONNECTION & COMMUNICATION WITH PERIPHERAL DEVICES

10. Connection & Communication with Peripheral Devices

Convenient Functions Relating to Output


4 If necessary, set zero return requirement.




What is zero return requirement?

After the previous sample (item to be weighed) has been removed from the pan, the weight reading must fall below the zero value and stability must be achieved before the next sample is placed on the pan, otherwise there will be no automatic output for this next sample. This function is intended to prevent two or more outputs being made for the same sample. For the zero return value, select either zero or 50% of the weight of the immediately preceding sample. Setting 50% saves time because even if the display doesn't return to zero, as long as stability is achieved, output will be possible if the next sample is placed on the pan.

If you are not setting zero return requirement, proceed to ► step 5.




When "RET. 0" is set:



5 Return to the weighing mode.

Press for about 3 seconds.



6 Place the container on the pan and press

→ 0/T →

The scale will be tared.

7 Place the sample into the container.

After (the stability mark) lights up, the displayed weight reading is automatically output.


8 Remove the sample from the pan.

If (the stability mark) lights up at a value close to zero, the displayed weight reading is automatically output.

10. Connection & Communication with Peripheral Devices


Convenient Functions Relating to Output

■ Printing / Outputting Continuously (Continuous Output Function)


This function allows displayed weight readings to be automatically output continuously in the same timing as the display refresh cycle (approximately 100 msec intervals) while weighing, without having to press .

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval


1 Press  for about 3 seconds in the weighing mode.

2 Select the continuous output function.


	
Stability Mark	Continuous Output Function
Lit	ON
Unlit	OFF



3 Change the setting.

Pressing  alternately sets the ON and OFF settings.

 [SET]




If OFF is selected, perform ► step 6.

► Steps 7 onward are not necessary in this case.

10. Connection & Communication with Peripheral Devices


Convenient Functions Relating to Output

- 4** Set whether starting and ending of the continuous output is performed manually by key operation.




Pressing alternately sets the ON and OFF settings.

[SET]




- 5** Set whether the non-averaged value is output as a continuous output value.



Pressing alternately sets the ON and OFF settings.

[SET]



- 6** Return to the weighing mode.

Press for about 3 seconds.

When OFF is set for "MANU" in ► step 4 continuous output starts. ► step 8 is not necessary in this case.



10. Connection & Communication with Peripheral Devices

Convenient Functions Relating to Output

7 Place the container on the pan and press

The scale will be tared.




8 Press (when ON is set for "MANU" in step 4).

After **READY** (the ready symbol) has gone off, displayed weight readings are continuously output.



9 Place the sample in the container.

Displayed weight readings will be automatically output in the same timing as the display refresh cycle (approximately 100 msec intervals).

Pausing and restarting the continuous output function


To pause the function, press  ( with the 9434 series). To restart it, press .

When OFF is set for "MANU" in step 4 ...

"MANU" is set to ON when  ( with the 9434 series) is pressed and the continuous output function is temporarily stopped.

INFO

Operation of (the communication symbol)

During continuous output, it may appear as though  (the communication symbol) is continuously lit. Note also that if the transmission speed for data output is slow the display will be unstable and the response time of the scale will also be slow.

When connected to a printer ...

For reasons linked to the performance of the printer, the data output interval will increase to longer than 100 msec.

10. Connection & Communication with Peripheral Devices

WindowsDirect Communication Function

■ What Is the WindowsDirect Communication Function?

In any Windows application (e.g. Excel or the weight input window of an analytical device), the numerical value displayed at the scale can be transferred to the cursor position just as if it had been entered from the keyboard. The main body of the scale has a keyboard function, so communication software is not required. As long as the status allows key entry, data can be directly sent to the target device.

INFO

WHAT TO DO IF ...

- ▶ After installing communications software in the PC and attempting communications, it is not possible to use the WindowsDirect communication function even though the OS is Windows. Refer to communications setting as described in "User-Specified Settings" (▶ Page 122)
- ▶ To control the scale from a PC, you must use command codes for programming
- ▶ A dedicated tool is required in order to run the WindowsDirect communication function with Windows Vista. For details, contact your Soehnle Professional representative.

■ Setting the Function


- ▶ Making the settings at the scale

When this setting is made, all of the communications settings are changed to those appropriate for WindowsDirect communication.
See "Communication Settings" (▶ Page 139).

1 Press for about 3 seconds in the weighing mode.

This opens the output menu.

2 Select WindowsDirect communication.



When "WINI" has been selected:



10. Connection & Communication with Peripheral Devices

WindowsDirect Communication Function

INFO

WHEN → (THE STABILITY MARK) IS LIT UP ...

The output data format has already been set. If you proceed to the next step in this status the setting will be cancelled and the scale will return to the status immediately before setting.

There are four types of output data format.

Indication	Output Data Format
WIN I	Numerical value + [ENTER]
WINI.U	Numerical value, unit symbol + [ENTER]
WIN-	Numerical value + [Tab]
WIN-.U	Numerical value, unit symbol + [Tab]

INFO

IF YOU HAVE SELECTED A FORMAT WITH [ENTER] APPENDED ...


In some Windows applications, ENTER may cause the current window to close. If this is the case, select a format with [Tab] appended.

3

Confirm and return to the weighing mode.

 [SET] → Press  for about 3 seconds.

This completes the setting procedure at the scale. When the function is set, **WIN** (the Win symbol) lights up.



► Connecting the RS-232C cable

1

Press  ( with the 9434 series) in the weighing mode.

With a 9435/9436 series scale, **READY** (the ready symbol) will light up and the standby mode will be established. With a 9434 series scale, the power will be shut off.


10

CONNECTION & COMMUNICATION WITH PERIPHERAL DEVICES

10. Connection & Communication with Peripheral Devices

WindowsDirect Communication Function


- 2 Remove the AC adapter from the power outlet.
- 3 Connect the RS-232C cable to the RS-232C connector on the rear of the scale.
- 4 Connect the RS-232C cable to the PC.



- Making the settings at the PC

As an example, the settings made with Windows XP are explained here.

- 1 Turn on the power to the PC
- 2 Click [start] (► [Settings]) ► [Control Panel].




10. Connection & Communication with Peripheral Devices

WindowsDirect Communication Function

3

Click [Accessibility Options] in the Control Panel.

The [Accessibility Options] screen will be displayed.




4

Enter a check mark at [Use Serial Keys] under the [General] tab.

IN ADDITION ...

INFO

- If you find [Administrative options] under the [General] tab too, enter a check mark here as well as at [Use Serial Keys].
- Remove all check marks from all checkboxes under tabs other than the [General] tab.



5

Clicks [Settings].

The [Settings for SerialKeys] dialog box will be displayed.

10


CONNECTION & COMMUNICATION WITH PERIPHERAL DEVICES

10. Connection & Communication with Peripheral Devices

WindowsDirect Communication Function

6

Select the serial port to be used for the connection with the scale and set the baud rate to "300".



7

Click [OK].

Return to the [Accessibility Options] window.

8


Click [Apply].

Wait a short time until the [Apply] character color fades.

9

Click [OK].

This completes the settings at the PC.



WHEN THE RS-232C PORT IS USED FOR ANOTHER PURPOSE ...

INFO

Once a serial key device has been activated, other software that uses the same RS-232C port will not operate normally. If a device such as an external modem or a plotter is connected to the same RS-232C port, after connecting the scale you must remove the check mark from the [Use Serial Keys] checkbox to invalidate serial key devices.


10. Connection & Communication with Peripheral Devices



WindowsDirect Communication Function


► Checking operation

- 1 **Connect the AC adapter to the power outlet (with the 9434 series, press ).**

The scale's self check display
(► Page 32) will be shown.




- 2 **When [OFF] is displayed, press  ( with the 9434 series) to enter the weighing mode.**




- 3 **At the PC, start up Excel (or another application such as Notepad).**

Key entry will be enabled and the cursor will be displayed at the position where entry is possible.



- 4 **Press  on the scale.**

The numerical value displayed on the scale will be transferred to the cursor position.



INFO

WHEN THE AUTO PRINT FUNCTION IS USED TOGETHER WITH THE WINDOWSDIRECT COMMUNICATION FUNCTION ...

Check that operation is normal even when using the auto print function.
"Printing / Outputting Automatically (Auto Print Function)", ► Page 116

10. Connection & Communication with Peripheral Devices

WindowsDirect Communication Function

■ Troubleshooting the WindowsDirect Communication Function

If the WindowsDirect communication function doesn't run properly, check the following points.

If this doesn't resolve the problem, contact your Soehnle Professional representative.

Q1 WindowsDirect communication has been set but it is not operating at all.

A1

- ▶ Check the type of communications cable used for the connection (Soehnle Professional authorized part or another part available on the general market) and the soundness of the connection.
- ▶ If a USB serial converter is used, depending on the circumstances at the setup there is a possibility that it has been automatically set to a COM port number higher than 4, and in this case you should reassign it to a COM port number that can be used by serial key devices (COM1 to COM4).
- ▶ It is possible that the driver used as an accessory with the USB serial converter has not been set up properly. Try uninstalling the driver and installing it again.
- ▶ Some notebook PCs feature a setting for disabling RS-232C ports as a power-saving measure. Before trying to use the WindowsDirect communication function, make the setting that enables the use of RS-232C ports.
- ▶ Communications with other applications and PCs via a LAN may interfere with the serial key device settings. Try using WindowsDirect communication without using the LAN.

Q2 The WindowsDirect communication function won't work after I restart the PC.

A2

- ▶ Some PCs don't recognize that a serial key device has been set when they start up. For details on how to deal with this, contact your Soehnle Professional representative.

Q3 I want to use the WindowsDirect communication function with Windows Vista.

A3

- ▶ Windows Vista doesn't have the serial device setting screen that is required to set the WindowsDirect communication function. For details on the setting, contact your Soehnle Professional representative.

Q4 Data is input to the PC as garbled characters.

A4

- ▶ Either the scale or the PC is not set for the WindowsDirect connection function. Make the settings again by referring to "Setting the Function" (▶ Page 122).

Q5 When data is input into Excel, the cursor doesn't move to another cell.

A5

- ▶ If a function for conversion to 2-byte characters is available in Windows, turn the setting for this function off.
- ▶ Click the [Edit] tab under [Options] in Excel and check [Move selection after Enter] (if cells move in response to keyboard input there is no problem).
- ▶ Check the input data in another application (e.g. Notepad).

Q6 The operation is sometimes abnormal.

A6

- ▶ Depending on the processing capability of the PC, malfunctions may occur if the communications speed is high. Set 300 bps for the communication speed. Malfunctions may also occur if the interval for data transmission from the scale is too short. Ensure that one batch of data is displayed on the screen before the next batch of data is sent. And if there is limited processing capability, don't use the continuous output function.
- ▶ When data is sent from the scale, don't touch the PC's keyboard or mouse.

10. Connection & Communication with Peripheral Devices

Connecting to a PC (RS-232C)

CAUTION



Use a correctly connected cable.


Instructions

The connection method and special accessory RS-232C cable described below do not guarantee normal operation with all types of PC.

When using the WindowsDirect communication function, see "**WindowsDirect Communication Function**"


▶ Page 122

INFO

Using a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval, when the weight value is unstable  Communication symbol blinks with no weight data output, when the weight value becomes stable this symbol lits with weight data output.

■ Cable Connection Method

For IBM PC/AT, DOS/V, and AX PC (D-sub 9-pin) (Straight connection)

PC Side			Scale Side		
RXD	2	_____	2		TXD
TXD	3	_____	3		RXD
DTR	4	_____	4		DSR
SG	5	_____	5		SG
DSR	6	_____	6		DTR
RTS	7		7		CTS
CTS	8		8		RTS
NC	9		9		

10

CONNECTION & COMMUNICATION WITH PERIPHERAL DEVICES

10. Connection & Communication with Peripheral Devices

Connecting to a PC (RS-232C)

■ Data Format

The details of the data format when standard setting 1 (*MODEL*) or data format 2 (*BFE2*) in the user settings has been selected in the communication settings

► Page 139) are given below.

Standard format

The data format when outputting negative values (for example: -123.456 g) is as shown below. The delimiter is a carriage return. The data length varies depending on the accompanying information, the number of characters used to indicate units, the delimiter and so on.

Data length for this example: 12 bytes

	1		2								3		4
Position	1	2	3	4	5	6	7	8	9	10	11	12	
ASCII code	2DH	20H	31H	32H	33H	2EH	34H	35H	36H	67H	20H	0DH	
Data	-		1	2	3	.	4	5	6	g		C/R	

Nr.	Position	Explanation
1	Position 1 (sign)	If the value is positive " " (a space) is entered and if the value is negative "-" (a minus symbol) is entered.
2	Positions 2 to 9 (absolute values)	If not all of the eight locations are used for a numerical value, a code representing a space is entered at the blank positions, as shown in the example.
3	Positions 10 and 11 (units)	If the unit designation comprises one character, a code representing a space is entered at position 11. If the unit designation comprises three characters, a total of 13 characters is sent.
4	Position 12 (delimiter)	This is a code that represents the delimiter.

10. Connection & Communication with Peripheral Devices

Connecting to a PC (RS-232C)

When the data length is longer than the standard

WHEN OUTPUTTING DATA WITH STABILITY INFORMATION INCLUDED

A code representing S or U is appended at the head of the data. Accordingly, the data length is increased by one byte.

Position	1	2	3	4
ASCII code	53H	2DH	20H	31H
Data	A	-		1

When stable: S (53H)
When unstable: U (55H)

WHEN THE DELIMITER "C/R+L/F" IS SELECTED

Two bytes are required for the delimiter information. One byte is added after position 12 in the standard format. Accordingly, the data length is increased by one byte.

Position	1	11	12	13
ASCII code	2DH	20H	0DH	0AH
Data	-	-	C/R	L/F

When there is "OL" or "-OL" (overload) output

The data format when "OL" is included is shown below.

Data length for this example: 12 bytes

Position	1	2	3	4	5	6	7	8	9	10	11	12
ASCII code	20H	20H	20H	20H	20H	4FH	4CH	20H	20H	20H	20H	0DH
Data						O	L					C/R

When the information is "-OL" (minus overload), the entry at position 1 is changed from a space to "-" (a minus symbol, ASCII code 2DH).

10. Connection & Communication with Peripheral Devices

Connecting to a PC (RS-232C)


■ Command Codes

Commands whose final character is a numeral, a letter of the alphabet, or a symbol other than "="

Each command code is sent to the scale with a delimiter appended at the end

Example 1:

PRINT (C / R)

This is the same as pressing 

Commands whose final character is "="

Each command code is sent to the scale followed by numerals (sometimes including a decimal point) and with a delimiter appended at the end.

Example 2:

ID = 1 2 3 4 (C / R)

This sets "1234" as the balance ID.

Example 3:

UW1 = 1 . 2 3 (C / R)

(Example for models with two places after the decimal point)

This sets 1.23 g as the unit weight for piece counting 1.

Example 4:



UW1 = 0 . 0 0 (C / R)

(Example for models with two places after the decimal point)

This clears the unit weight for piece counting 1.

Working from the PC connected to the scale, it is possible to instruct a weighing operation or to display a numerical value of your choice at the scale.

Display panel of the scale



INFO

OUTPUT TO THE PC

In order to distinguish between instruction information from the PC and the scale's weight display data, "." is converted to "-" before output.

10. Connection & Communication with Peripheral Devices

Connecting to a PC (RS-232C)

Echo-back commands

A character string comprising N characters following an echo-back command "{" or "}" and terminated by a delimiter is resent unchanged from the scale (provided unprocessed commands do not remain in the scale's receive buffer, and $N \leq 30$).

Example 5:

**A B C D E F G 1 2 3 4 5
(C/R)**

After receiving this command, the scale outputs A B C D E F G 1 2 3 4 5 (C/R). When a printer is used in combination with the scale, this character string can be printed by the printer (printing of any required character string).

INFO

TO PRINT WITH THE PRINTER

Only use upper case letters of the alphabet, numerals and some symbols (including the decimal point and signs), and limit the string to within 15 characters.

Command list

Data output

Command	Function
---------	----------

D01 *1	Continuous output
D02 *1	Continuous output at stability
D03 *1	Continuous output with stability information
D04 *1	Forced single output
D05	Single output
D06	Auto print setting
D07	Single output with stability information
D08	Single output at stability
D09	Cancel output

INFO

ACCEPTANCE OF COMMANDS

Depending on the status of the scale, even though a command is output it may not be accepted, with the display of "COM ERR".

Key operation

Command	Function
---------	----------

BREAK Q	Break key
CAL	Calibration key
TARE T	Zero setting / taring key
PRINT	Output key

*1: Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

10

CONNECTION & COMMUNICATION WITH PERIPHERAL DEVICES

10. Connection & Communication with Peripheral Devices

Connecting to a PC (RS-232C)

Application weighing

Command	Function	Values
R	Cancels application weighing mode setting	
Piece counting		
PCS□	Sets the piece counting (PCS) mode	□: 1 to 5 mode numbers
UW□ = XX.XXX	Sets the unit weight	XX.XXX : Setting value
UW□	Reads the unit weight	
UB□ = XXX	Sets the reference number of pieces	XXX : Reference number of pieces value
UB□	Reads the reference number of pieces	
RECAL	Recalculates the unit weight	
Percentage weighing		
G	Switches between percentage (%) and gram units	
%	Sets the percentage weighing mode	"%" can also be used.
Formulation		
M	Sets the formulation mode	

Other functions

Command	Function	Values
Comparator		
TRGT	Establishes the target mode	
TARGET = XX.XX	Sets the target in the target mode	XX.XX :
LIMIT = XX.XX	Sets the target range in the target mode	Setting value
CHKW	Establishes the checkweighing mode	
OVR.RNG = XX.XX	Sets the checkweighing range upper limit value in the checkweighing mode	
UND.RNG = XX.XX	Sets the checkweighing range lower limit value in the checkweighing mode	XX.XX:
HI.LIM = XX.XX	Sets the pass range upper limit value in the checkweighing mode	Setting value
LO.LIM = XX.XX	Sets the pass range lower limit value in the checkweighing mode	

10. Connection & Communication with Peripheral Devices

Connecting to a PC (RS-232C)

Other functions

Command	Function	Values
GO	Reads the results [Response command] HL (above "too heavy" range) HI (too heavy) OK (appropriate weight, pass) LO (too light) LL (below "too light" range)	

*1: Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

System-related commands

Command	Function	Values
ID = XXXX	Sets the scale ID	XXXX: Setting value
ID	Reads the scale ID	
STATE	Outputs the setting details	

Commands relating to calibration

Command	Function	Values
ECAL *1	Starts external calibration	
ECAL.W = XXX.XXX *1	Sets the reference weight value (W ref) for calibration	XXX.XXX: Setting value
ETEST *1	Starts an external calibration check	
ICAL	Executes calibration with the internal weight	
ITEST	Executes a calibration check with the internal weight	

Commands relating to zero / taring

Command	Function	Values
ZRNG = X.XXX *1	Sets the zero range	X.XXX: Setting value

10. Connection & Communication with Peripheral Devices

Connecting to a PC (RS-232C)

Commands relating to unit registration

Command	Function	Values
g	Sets gram units	
mg *1	Sets milligram units (only accepted by models capable of displaying 0.001 g)	
kg	Sets kilogram units	
ct	Sets carat units	
mom*1	Sets momme units	
CU □ *1	Sets / cancels user-specified units	<input type="checkbox"/> 0: Cancel, 1: Set
UCOFF = X.XXXX*1	Sets the conversion factor for user-specified units	X.XXXX: Setting value
UDIG = X.XXX*1	Sets the minimum displayed value for user-specified unit conversion	X.XXX: Minimum displayed value

*1: Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

Other companies' commands

Command	Function	Values
TI	Immediate taring (Mettler)	
A	Single output at stability (Mettler)	
SI *1	Sofortige Einzelausgabe (Mettler)	
SIR *1	Continuous output (Mettler)	
SR *1	Continuous output at stability (Mettler)	
(ESC) P	Immediate single output (Sartorius) ESC = &H1B	
(ESC)T	Immediate taring (Sartorius) ESC = &H1B	

Others

Command	Function	Values
" " (space)	Buffer clear command	
# = XXXXXXX	Enters and displays a numerical value	XXXXXXX : Numerical value
{ □ □ ...	Echo-back mode	□ □ ...: Character string

10. Connection & Communication with Peripheral Devices

Connecting to a Printer

9434/9435/9436 series scales can be connected to the following electronic printers (available as options).

- ▶ EP-80 electronic printer
- ▶ EP-90 electronic printer


INFO

OUTPUTTING TO A PRINTER WHILE SIMULTANEOUSLY USING THE WINDOWSDIRECT COMMUNICATION FUNCTION ...


This is possible with the EP-80 and EP-90 electronic printers. For details, refer to the printer instruction manuals.

When using a printer, connect it to the scale by following the procedure below.

- 1 Turn off the power to the scale and the printer.**




- 2 Using the cable supplied as an accessory with the printer, securely connect the DATA I/O connector at the scale and the connector at the printer.**



- 3 Turn on the power to the scale.**

- 4 Turn on the power to the printer.**



10. Connection & Communication with Peripheral Devices


Connecting to a Printer

INFO

WHAT TO DO IF ...

- ▶ When turning the power off, turn off the power to the printer first, then the power to the scale.
- ▶ For more information on the printer, see the printer instruction manual.

INFO

Using a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval, when the weight value is unstable  Communication symbol blinks with no weight data output, when the weight value becomes stable this symbol lights with weight data output.

10. Connection & Communication with Peripheral Devices

Communication Settings

This section explains the menu settings that determine the communication specifications when the scale is connected to a PC, printer, or other device.

For information on the WindowsDirect communication function, see “WindowsDirect Communication Function” (▶ Page 122). The settings made here are effective simultaneously for RS-232C and the DATA I/O communication ports. If you are connecting the printer to the DATA I/O connector, set the communication specifications of the scale to “MODE1”. The default setting is “MODE1”.

Apart from this default setting, another five modes comprising frequently used combinations of communication settings are provided.

Selecting one of the settings from “MODE1” to “MODE5” allows you to set all of the following items at once: baud rate (communication speed), parity (bit length), stop bit, handshake, data format, delimiter.
“Standard Settings (MODE)” ▶ Page 140

The user can set each item according to requirements.
“User-Specified Settings”,
▶ Page 140

WindowsDirect Communication		Standard Settings 1	Standard Settings 2	Standard Settings 3	Standard Settings 4	Standard Settings 5	User-Specified Settings
Display with user-specified settings	WINI etc.	MODE.1	MODE.2	MODE.3	MODE.4	MODE.5	MODE.U
Relevant manufacturer	Soehnle Professional	Soehnle Professional (standard)	Soehnle Professional (responses given*)	Mettler	Sartorius	A&D	–
Baud rate (communication speed)	300	1200	1200	2400	1200	2400	Any required setting
Parity (bit length)	None (8)	None (8)	None (8)	Even (7)	Odd (7)	Even (7)	Any required setting
Stop bit	1	1	1	2	2	2	Any required setting
Handshake	Hardware	Hardware	Hardware	OFF	Hardware	OFF	Any required setting
Data format	WindowsDirect communication	Soehnle Professional standard	Soehnle Professional standard	Mettler standard	Sartorius standard	A&D standard	Any required setting
Delimiter	WindowsDirect communication	C/R	C/R	C/R+L/F	C/R+L/F	C/R+L/F	Any required setting

*: The scale can return responses to commands from a PC. When a command is received normally, OK (C/R) is returned and when a command is received abnormally, NG (C/R) is returned.

10. Connection & Communication with Peripheral Devices

Communication Settings


■ Standard Settings (MODE)

Make a selection from the setting combinations "MODE1" to "MODE4".

- 1** Press **PRINT** for about 3 seconds in the weighing mode.

This opens the output menu.

- 2** Select communication setting.



(Select the mode) → **MENU** **ENTER** [SET]



When "MODE2" is selected



- 3** Return to the weighing mode.

Press **RELEASE** for about 3 seconds.




■ User-Specified Settings

In this setting each of the communication settings can be set according to the user's requirements.

- 1** Press **PRINT** for about 3 seconds in the weighing mode.

This opens the output menu.

- 2** Select user-specified setting.



[MODE.U] → **MENU** **ENTER** [SET]



10. Connection & Communication with Peripheral Devices

Communication Settings


3 Make the communication settings according to your own requirements.

Set the following items as necessary.

Setting the baud rate (communication speed)

UNIT [BPS] → S → UNIT
FUNC → FUNC

(Select the baudrate) → MENU ENTER [SET]




Indication	B.300	B.600	B.1200	B.2400	B.4800	B.9600	B.19.2k	B.38.4k
Baud rate	300 bps	600 bps	1200 bps	2400 bps	4800 bps	9600 bps	19.2k bps	38.4k bps

Setting the parity (bit length)

UNIT [PARITY] → S → UNIT
FUNC → FUNC

(Select the parity) → MENU ENTER [SET]




Indication	P.NONE	P.ODD	P.EVEN
Parity (bit length)	No parity, 8-bit length	Odd parity, 7-bit length	Even parity, 7-bit length

Setting the stop bit

UNIT [STOP] → S → UNIT
FUNC → FUNC

(Select the stop bit) → MENU ENTER [SET]





Indication	S.1	S.2
Stop bit	Stop bit = 1 bit	Stop bit = 2 bits

10. Connection & Communication with Peripheral Devices

Communication Settings

Setting the handshake



Indication	HS.OFF	HS.HW	HS.SW	HS.TIM
Handshake	No handshake	Hardware handshake	Software handshake	Timer handshake



INFO

WHAT TO DO IF ...

The default setting is "hardware handshake".

- ▶ When connecting to a printer, select "hardware handshake".
- ▶ When connecting to a PC, select "no handshake".

Setting the data format



Indication	DF.1	DF.2	DF.3	DF.4	DF.FRE
Data format	Data format 1 This is Soehnle Professional standard format. Normally, make this setting.	Data format 2 This is an expansion of the data format 1 function.	Data format 3 This is the same format as used by Mettler scales.	Data format 4 This is the same format as used by Sartorius scales.	Data format 5 This is a format that allows the leading bytes and number of send data to be set freely. The leading bytes can be set in the range 1 to 17 and the number of send data can be set in the range 8 to 23.

10. Connection & Communication with Peripheral Devices

Communication Settings

Setting a delimiter




Delimiter: A symbol used to partition individual data items and individual commands

Indication	CR	LF	CR+LF	COMMA	WINI WINIU WIN- WIN-U
Delimiter	CR	LF	CR+LF	Comma	WindowsDirect communication*

*: Batch set all of the communication settings for the WindowsDirect communication function by following the procedure in "Setting the Function" (► Page 122).

4

Return to the weighing mode.


Press  for about 3 seconds.

10

CONNECTION & COMMUNICATION WITH PERIPHERAL DEVICES

10. Connection & Communication with Peripheral Devices

Output Timing Change Function

Data can be set to output without waiting for detection of stability (immediate output), or to output only after detecting stability (output after stability), when  is pressed.

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

1 Press for about 3 seconds in the weighing mode.

This opens the output menu.

2 Select the output timing change function.




Stability Mark	Output Timing Change Function
Lit	When "immediate output" is set
Unlit	When "output after stability" is set



Check the presence or absence of the stability mark.

3 Change the setting.


Pressing  alternately selects "immediate output" and "output after stability".

 [SET]



When "immediate output" is set, the stability mark is lit.

4 Return to the weighing mode.

Press  for about 3 seconds.

11. Maintenance

Maintaining the Scale


CAUTION



Instructions


Before starting maintenance on the scale, disconnect the AC adapter from the power outlet.

If you carry out maintenance with the AC adapter left plugged into the power outlet, you may sustain an electric shock.



Pan

The pan can be removed from the body of the scale and washed with water. Dry it thoroughly before fitting it back on the scale.



Display

Avoid using organic solvents, chemical agents or cloths impregnated with chemicals since they will damage the coating of the scale and the display panel. If the scale is used in an environment where it gets dirty easily, use the protective in-use cover available as a special accessory (option).

Main body


Wipe over with a soft cloth moistened with a little neutral detergent and well wrung out.



Glass door

The door can be removed and the door rails can be wiped over or replaced. For details on how to remove the door, see **"Removing the Glass Door"**

► Page 147



11. Maintenance

Maintaining the Scale

■ Removing the Glass Door

With small pan models of the 9435/9436 series of scales, the glass door can be removed to clean the door rails.

CAUTION




Handle the glass door with due care.

Instructions

- ▶ Take care when handling the glass door so as not to crack it.
- ▶ Take care not to injure your hands on the door rail.
- ▶ Exercise due care when handling broken glass.

1

Remove the pan and pan supporter.



2


Turn the knob on the inner side of the handle to remove the handle.

CAUTION



Prohibitions

Do not touch the pan support shaft.
This could damage the scale.



3

Pull the glass door out from the rear.


CAUTION



Instructions

When fitting the glass door, be sure to fit the knob.

If you forget to fit the knob the glass door could fall off.



11

MAINTENANCE

11. Maintenance

Inspection

Since the scale may develop error due to its application and environment of use, it must undergo both daily and periodic inspections in order to properly maintain its required performance and functions. However, since the management standards governing the content of these inspections (methods, judgment criteria, etc.) will differ depending on the purpose of use, management goals, they must be determined by the customer.

If the content of the inspections is made too lax, the risk that you will continue to use the scale without discovering an abnormality increases, but if it is excessively strict it may reduce working efficiency, so you should take the care to devise balanced inspection content, considering the risks, the performance that is required in the work to be done. This section indicates the guidelines for daily inspections and periodic inspections. Please use these guidelines for reference when deciding the practical details of your own inspections.

■ Daily Inspections

Daily inspections are inspections performed on a daily basis (for example before starting work) by the person who actually uses (or manages) the scale.

The points inspected in daily inspections can, if you like, be reduced to the minimum necessary.

Here are some examples for your reference.

	Daily Inspection [Reference Example 1]	Daily Inspection [Reference Example 2]
Frequency of inspection	Once per day	Once to several times per day (as required)
Inspection timing	Before the start of work	Before the start of work and when performing important weighing operations
Method of inspection	Observe the instrumental error at a single point. Set the "observation point" as a point a little above the upper limit value of the range in which the scale is actually used to weigh.	Observe the instrumental error at a single point. As the point to be observed before the start of work, set a point a little above the upper limit value of the range in which it is possible that actual measurements will be made.
Criterion of judgment	To be accurate to within ± 5 at one decimal place to the right of the digit where accuracy is required when actually weighing with the scale.	To be accurate to within ± 5 at one decimal place to the right of the digit where accuracy is required when actually weighing with the scale.



What is instrumental error?

This is the amount of the discrepancy between the value indicated by the scale and the correct value. It is assessed as the difference between the weight reading when a weight that corresponds to the observation point is weighed on the scale and the actual weight value of that weight.

For details on weights, see "About Weights"

► Page 150

11. Maintenance

Inspection

■ Periodic Inspections

Periodic inspections are inspections that are performed periodically (for example once a year). The content of periodic inspections must cover all aspects including performance and functions.

An overview is given below.

Overview of Periodic Inspection [Reference Example]

Frequency of inspection	Once a year
Inspection timing	Any day during the established month
Method of inspection	<p>Check for abnormalities in the following functions and external appearance.</p> <ul style="list-style-type: none">▶ Display panel▶ Menu operation keys / operation keys▶ Pan▶ Level <p>Check the following aspects of performance:</p> <ul style="list-style-type: none">▶ Repeatability: Weigh a weight that corresponds to approximately half of the weighing capacity of the scale five to ten times and assess the dispersion in the weight readings obtained.▶ Eccentric error: Assess the difference in the weight readings obtained when a weight corresponding to one fourth to one third of the weighing capacity of the scale is placed in the center of the pan and at a position shifted from the center by a specified distance.▶ Instrumental error: Decide on three to five observation points and assess the difference between the values obtained when weights corresponding to these points are weighed on the scale and the actual weight values of the weights.
Criterion of judgment	To be accurate to within ± 5 at one decimal place to the right of the digit where accuracy is required when actually weighing with the scale.



For details on weights,
see "About Weights"

▶ Page 150

11. Maintenance

About Weights

In order to establish and maintain the performance of the scale, weights must be used to accurately adjust the scale's scale, and to check its adjustment.

With the 9434/9435/9436 series scales, weights are used when performing calibration (► Page 58) and inspections (► Page 148) in the environment in which the scale is actually used. The weights should be prepared in advance and managed properly.

INFO

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

■ Types of Weight and Their Selection

There are many types of weights.

Select the appropriate weights for the specifications of your scale by referring to the following table.

► Selecting the class of weight

As the main form of classification, weights are normally divided into classes according to their degree of accuracy.

Select the most appropriate class of weights to be used for calibration and inspection of the scale, based on the type of the scale.

The table below shows the classes of weight and the applicable scales.

Class of Weight	Applicable Type of Scale		
	Minimum Indication	Resolution*	Common Name
E2	Less than 1 mg	Around 1/1,000,000 or better	Analytical scales
F1	1 mg or greater	Around 1/100,000 or better	Toploading scales
F2	1 mg or greater	Around 1/100,000 or lower	Toploading scales
M1	10 mg or greater	Around 1/10,000 or better	Scales, etc.

* "Resolution" means: minimum indication / weighing capacity

11. Maintenance

About Weights

► Selecting the calibration weights to be used

Now you must select the "indicated weight" of the weight to be used (how many grams it should be).

The weights of weights are set with the smallest at 1 mg and progressing in the sequence 1 mg, 2 mg, 5 mg, ... as shown below.

1 mg, 2 mg, 5 mg, 10 mg ... 1 g, 2 g, 5 g, 10 g, 20 g, 50 g, 100 g ...

When selecting a weight to be used for calibrating a scale, you are recommended to select one that is close to the weighing capacity of the scale.

The table below shows the recommended calibration weights to be used for scales with different weighing capacities.





Weighing Capacity of Scale	Recommended Weight of Weight for Calibration
64 g (320 ct)	60 g (50 g + 10 g)
124 g (620 ct)	100 g
220 g	200 g
320 g	300 g (200 g + 100 g)
420 g	400 g (200 g + 200 g)
620 g	600 g (500 g + 100 g)
2200 g	2 kg
3200 g	3 kg (2 kg + 1 kg)
4200 g	4 kg (2 kg + 2 kg)
6200 g	6 kg (5 kg + 1 kg)

For information on the range of weights that can be used to calibrate scales (i.e. values that can be entered as the weight value) see "Calibration range with external weights" in "Specifications". (► Page 161)

It is also possible to calibrate a scale with a weight that is not close to the weighing capacity of the scale. However, if you do this, when weighing in the range that exceeds the weight value that was used for calibration, the performance may deteriorate proportionately (the instrumental error may become larger).


12. Troubleshooting

What to Do If ...

Symptom	Probable Cause(s)	Countermeasure	See:
Nothing is displayed on the display panel.	<ul style="list-style-type: none"> ▶ The power cable is disconnected. ▶ The main switch on the distribution panel is off. ▶ The power supply voltage is wrong. 	▶ Check the power supply and voltage and make the connections correctly.	▶ Page 161
The display doesn't change when a sample (item to be weighed) is placed on the pan.	▶ The pan has been displaced.	▶ Set the pan correctly on the scale.	▶ Page 27
The display fluctuates and  (the stability mark) does not appear readily.	▶ The scale has been installed in an unstable environment.	<ul style="list-style-type: none"> ▶ Eliminate the effects of vibration and air movement. ▶ Install the scale on a robust platform. 	▶ Page 23
	▶ The pan supporter caps have come off.	▶ Fit the pan supporter caps	▶ Page 27
	▶ The protective in-use cover is touching the pan.	▶ When using the protective in-use cover, make sure that it is fitted snugly against the surface of the scale body.	-
	▶ The glass door of the windbreak is open (9435/9436 series small pan models only).	▶ Close all the glass doors before reading the display.	-
The weighing result is not accurate.	▶ Span calibration has not been performed.	▶ Perform span calibration.	▶ Page 60
	▶ Is the display at zero before weighing?	▶ Press  to set the display at zero before weighing.	▶ Page 40
The units that you want to use are not displayed.	▶ The units that you want to use have not been set.	▶ Set the units that you want to use for 	▶ Page 88
Menu operations are not possible.	▶ Menu operation is locked.	▶ Release the menu lock.	▶ Page 44
The WindowsDirect communication function cannot be used.	<div> For details, see "Troubleshooting the WindowsDirect Communication Function".  </div>		▶ Page 128

12. Troubleshooting

Responding to Messages

Symptom	Probable Cause(s)	Countermeasure	See:
ERR H (Hardware error)	<ul style="list-style-type: none"> ▶ There is a fault in the hardware, such as the temperature sensor or internal weight mechanism (9436 series only). ▶ There is an error in the internal system data. 	<ul style="list-style-type: none"> ▶ Disconnect the AC adaptor or remove the batteries and turn the power back ON. If the same message is still displayed, contact your Soehnle Professional representative. 	▶ Page 32
ERR C (Span calibration error)	<ul style="list-style-type: none"> ▶ The scale has a large drift of the zero point or sensitivity. ▶ A container is placed on the pan. ▶ The pan is displaced. ▶ The wrong weight has been placed on the pan. 	<ul style="list-style-type: none"> ▶ Press  with the 9434 series) to return to the weighing mode. Place the correct weight in the center of the pan. ▶ After checking that the pan is correctly installed and that nothing is placed on it, turn the power back ON and execute span calibration again. 	▶ Page 60 ▶ Page 64
ERR N (Numerical value entry error)	<ul style="list-style-type: none"> ▶ Either a mistake has been made when entering the value or the value is not appropriate. 	<ul style="list-style-type: none"> ▶ After the error is displayed, the scale returns to the status immediately before the error occurred. Enter the correct numerical value. 	▶ Page 51
ERR W (Operation error)	<ul style="list-style-type: none"> ▶ The operation used is wrong. 	<ul style="list-style-type: none"> ▶ After the error is displayed, the scale returns to the status immediately before the error occurred. At this point, follow the correct operation. 	–
COM ERR (External input error)	<ul style="list-style-type: none"> ▶ An unrecognizable command code has been received. 	<ul style="list-style-type: none"> ▶ After the error is displayed, the scale returns to the status immediately before the error occurred. At this point, set the correct command code. 	▶ Page 132
OL - OL (overload)	<ul style="list-style-type: none"> ▶ The pan is displaced. ▶ The pan supporter caps (9435 series large pan models only) have come off. ▶ The weighing capacity has been exceeded. 	<ul style="list-style-type: none"> ▶ Set the pan correctly on the scale. ▶ Fit the pan supporter caps (9435 series large pan models only). ▶ Use the scale within its weighing capacity. 	▶ Page 27 ▶ Page 161
ABORT (Operation aborted)	<ul style="list-style-type: none"> ▶ The calibration or standard value setting operation has been aborted. 	<ul style="list-style-type: none"> ▶ After this is displayed, the scale returns to the operable state. 	–
WAIT (Waiting for permission for the operation)	<ul style="list-style-type: none"> ▶ This message is displayed in order to avoid unnecessary key operations. 	<ul style="list-style-type: none"> ▶ After this is displayed, the scale returns to the operable state. 	–
BUSY (Load detected)	<ul style="list-style-type: none"> ▶ There was something placed on the pan when calibration was started. 	<ul style="list-style-type: none"> ▶ Take the item off the pan. The message will be cleared automatically and you will be able to continue calibration. 	▶ Page 60

13. For Your Information

Turning the Power ON and OFF

■ Auto Power-Off Function



When the auto power-off function is turned on, the liquid crystal display will go fully off or the power will be shut off automatically if there is no weighing or key operation during the set time.

- ▶ 9435/9436 series: The liquid crystal display goes fully off.
- ▶ 9434 series: The power is shut off.

1 Press in the weighing mode.



This opens the main menu.

2 Select the Auto power-OFF function.




What is the current situation?


What do you want to do?

Stability Mark	Auto Power-Off Function		To Set / Update	To Cancel
Lit	ON	→	Press  and go to step 3.	Press  and go to step 4.
Unlit	OFF	→	Press  and go to step 3.	Go to step 4.

3 Enter the time (in minutes).

(Enter the time (in minutes).) →  [SET]

"Entering Numerical Values", ▶ Page 51



INFO


SETTING TIME FOR AUTO POWER-OFF FUNCTION

The upper limit time which can be set for the auto power-off function is 10 minutes.

13. For Your Information


Turning the Power ON and OFF

4 Return to the weighing mode.

Press  for about 3 seconds.

■ Setting the Startup Display


Select the startup display from one of the three following types.

Weighing mode	After the power is turned on, the scale proceeds automatically to the weighing mode.
OFF display	After the power is turned on, the scale stops with the "OFF display". When any of the keys is pressed during the OFF display the scale automatically proceeds to the all segments lit display and then to the weighing mode.
All segments lit	After the power is turned on, the scale stops with the "OFF display". When any of the keys is pressed during the OFF display, the scale stops with all display segments lit. Pressing  while all segments are lit takes you to the weighing mode.


1 Press in the weighing mode.

This opens the main menu.

2 Select setting of the startup display.



3 Select the type of startup display.



➔ (the stability mark) lights up for the set start display.

Weighing mode




OFF display



All segments lit



4 Return to the weighing mode.

Press  for about 3 seconds.
The startup display is now set.

13. For Your Information



Backlight ON/OFF (9434 Only)

This setting can only be made with 9434 series scales (with the 9435/9436 series, the backlight is ON all the time).

1 Press in the weighing mode.


This opens the main menu.

2 Select the backlight.




Stability Mark	Backlight
Lit	ON
Unlit	OFF


3 Change the setting.

Pressing  alternately sets the ON and OFF settings.



4 Return to the weighing mode.

Press  for about 3 seconds.



INFO

BACKLIGHT AUTO OFF

Even when the backlight setting is made ON (lit), the backlight automatically goes off if there is no key operation or change in the loading status on the pan for 15 seconds.

13. For Your Information


Changing the Password

To execute menu reset (► Page 53), to set or cancel menu lock (► Page 44), or to execute calibration of the internal weight (► Page 69) you have to input a password. "9999" is set as the default password, but this can be changed by following the procedure below.


1 Press in the weighing mode.

This opens the main menu.


2 Select the password.



3 Enter the current password.




4 Enter the new password.




"Entering Numerical Values", ► Page 51

5 Confirm.



To cancel at this point, press  (with the 9434 series). The scale will return to the status after ► step 2, without setting the value entered in ► step 3.


To confirm the password, proceed as follows.



13. For Your Information

GLP Output Function


6 Return to the weighing mode.

Press  for about 3 seconds.

GLP Output Function

On turning the GLP output function ON, you can add the scale ID and other information to the calibration record (► Page 72) and weight reading outputs.

Example printout from printer
(When the GLP output function is set to ON)






■ Setting the GLP Output Function

1 Press for about 3 seconds.

This opens the calibration menu.

2 Select the GLP output function.

  [GLP.OUT]	
Stability Mark	GLP Output Function
Lit	ON
Unlit	OFF



13. For Your Information

GLP Output Function


INFO


9434 SERIES ...


The menu for the GLP data output will be shown like this: [CAL.REC]

3

Change the setting.


Pressing  alternately sets the ON and OFF settings.

 [SET]



4


Return to the weighing mode.

Press  for about 3 seconds.

INFO

ON SETTING THE GLP OUTPUT FUNCTION TO ON AND OUTPUTTING WEIGHT READINGS ...

A long time is required to output one weight reading.
In addition, when the scale is used in combination with both a PC and printer (option), data may not be printed correctly at the printer. See the setting conditions below.

Handshake Settings in the Communication Settings  Page 155)	Rough Time Required for Output of One Weight Reading		
	Printer Only	PC Only	Both Printer and PC used
OFF	Approx. 10 sec.	Approx. 10 sec.	Correct printing is not possible
SW (software)	Approx. 33 sec.	Approx. 33 sec.	Approx. 33 sec.
HW (hardware)	Approx. 10 sec.	Approx. 10 sec.	Correct printing is not possible
TIM (timer)	Approx. 60 sec.	Approx.. 60 sec.	Approx. 60 sec.

INFO

ON SETTING THE GLP OUTPUT FUNCTION TO ON AND USING THE COMMAND
CODE "D01 (CONTINUOUS OUTPUT)"...

No items other than weight readings are output.

13. For Your Information

GLP Output Function


■ Setting a Scale ID

When managing multiple scales, by setting a four-digit management number (ID) and turning the GLP output function ON, you can add the scale ID to calibration records (► Page 72) and weight reading outputs.


1 Press in the weighing mode.

This opens the main menu.


2 Select setting of a scale ID.




3 Enter the required numerals (max. 4 digits).




"Entering Numerical Values", ► Page 51
The default ID is "0000".



4 Return to the weighing mode.



Press  for about 3 seconds.

13. For Your Information

Specifications

■ 9435/9436 series

Model Name	9436.04.001 9435.04.001	9435.42.001
g Accuracy class	II	
Capacity	420 g	4200g
Verification scale interval (e)	0.01g	0.1g
Number of verification scale interval	42000	42000
Scale interval (d)	0.001g	0.01g
Range of use	0.02g – 420g	0.5g – 4.200g
Response time *1	2.5 seconds	
Ambient operating temperature (°C)	10 – 30°C	
Pan size (mm)	Approx. Φ110	Approx. 167 (B) × 181 (T) *2
Main body dimensions (mm)	Approx. 206 (B) × 291 (T) × 241 (H)	Approx. 200 (B) × 291 (T) × 80 (H)
Main body weight	9436: approx. 4.2 kg 9435: approx. 3.8 kg	9436: approx. 3.2 kg 9435: approx. 2.8 kg
Display	LCD with backlight	
Power requirements	AC adaptor (Output 12 V, 1 A)	
I/O terminal	RS-232C, DATA I/O	
Contamination level	2	
Overvoltage category	Class II	
Height above sea level	up to 2000 m	
Installation site	indoor use only	
AC adaptor (primary)	AC 100-240 V, 400 mA 50/60 Hz	

*1 The response time is a representative value.

*2 The size of the pan is the dimension of the face on which the sample (thing being weighed) is placed. The dimension expresses the flat face size of the pan. Since the pan has a tapered shape, its outer dimension is a little larger.

13. For Your Information

Specifications

■ 9434 Serie

Model Name		9434.04.001	9434.06.001	9434.42.001	9434.62.001
Weighing capacity		420 g	620 g	4200 g	6200 g
Minimum indication		0.01 g			
Range of external weights for calibration		100 – 420 g	100 – 620 g	1.000 – 4200 g	1.000 – 6.200 g
Repeatability (standard deviation)		≤ 0.01 g			
Linearity		±0.02 g			
Response time *1		2.0 seconds			
Ambient temperature		5 – 40 °C			
Temperature coefficient for sensitivity (10 – 30 °C)		± 10 ppm/°C	± 5 ppm/°C	± 10 ppm/°C	± 5 ppm/°C
Pan size (mm)		Φ110		f160	
Main body dimensions (mm)		Approx. 199 (B) × 260 (T) × 77 (H)			
Main body weight		Approx. 1.5 kg			
Display		LCD with backlight			
Nominal current supply		DC 9 – 12 V, 1 A			
Power requirements	AC adaptor	Output 12 V, 1 A			
	Dry cell batteries	Six size AA alkaline dry cell batteries For 40 hours of continuous use (Back light off) *2			
I/O terminal		RS-232C, DATA I/O			
Contamination level		2			
Overvoltage category		Class II			
Height above sea level		up to 2000 m			
Installation site		indoor use only			

*¹ The response time is a representative value.

*² When the backlight is lit, the time that the scale can be used continuously is reduced.

13. For Your Information

Maintenance Parts

■ 9435/9436 series

Maintenance parts list

Part Name	Part Number (P/N)	Remarks
Pan (large pan)	321-64587	
Pan (small pan)	321-41418-10	
Pan (carat)	321-41225	9435/9436 series for carat use
Pan with grip	321-41906-01	9435/9436 series for carat use
Pan ring	321-41205-11	9435/9436 series for carat use
Pan supporter (small pan)	321-64589	
Pan supporter (carat)	321-64518	9435/9436 series for carat use
Underplate (small pan, carat)	321-64593	9435/9436 series, small pan / for carat use
Pan supporter cap (large pan)	321-64591	
Glass door ASSY (right)	321-64583-01	9435/9436 series, small pan / for carat use
Glass door ASSY (left)	321-64583-02	9435/9436 series, small pan / for carat use
Glass door ASSY (top)	321-64581	9435/9436 series, small pan / for carat use
Mounting knob for glass door	321-62787-01	9435/9436 series, small pan / for carat use

Optional

Part Name	Part Number (P/N)	Part Number for RoHS	Remarks
Electronic printer EP-80	321-62675-01 (w/o AC adaptor)	321-80016-01 (w/o AC adaptor)	Impact dot type, can be used with the WindowsDirect communication function
Electronic printer EP-90	321-62675-11 (w/o AC adaptor)	321-80016-11 (w/o AC adaptor)	The EP-80 with a numeric keypad
RS-232C cable	321-61967		D-Sub 9-pin for DOS/V (length 1.5 m)
USB – serial conversion kit	321-62520-05		With cable (321-61967)
All-surface protective cover (5 pcs.)	321-64523-10		Specifically for 9434 series large pan models
Display panel protective cover (5 pcs.)	321-64522-10		9435/9436 series, small pan / for carat use
Level screws	321-64540		

13. For Your Information

Maintenance Parts

■ 9434 serie

Maintenance parts list

Part Name	Part Number (P/N)	Remarks
Pan (large pan)	321-63871	
Pan (small pan)	321-41418-10	
Pan supporter (large pan)	321-63873	
Pan supporter (small pan)	321-63835	
Pan ring (large)	321-63830	
Pan ring (small)	321-63831	
Battery cover	321-63838	

Optional

Part Name	Part Number(T/N)	Part Number for RoHS	Remarks
Electronic printer EP-80	321-62675-01 (w/o AC adaptor)	321-80016-01 (w/o AC adaptor)	Impact dot type, can be used with the WindowsDirect communication function
Electronic printer EP-90	321-62675-11 (w/o AC adaptor)	321-80016-11 (w/o AC adaptor)	The EP-80 with a numeric keypad
RS-232C cable	321-61967		D-Sub 9-pin for DOS/V (length 1.5 m)
USB – serial conversion kit	321-62520-05		With cable (321-61967)
All-surface protective cover (5 pcs.)	321-63827-12		Specifically for the 9434 series (common to large pan and small pan)
Display panel protective cover (5 pcs.)	321-63827-11		Specifically for the 9434 series (common to large pan and small pan)
Level screws	321-64540		

The part numbers, specifications, etc. indicated here are subject to change without notice.

13. For Your Information

List of Functions That Can Be Used in Combination

A correspondence table for application functions, comparator functions and output functions is shown below. It shows whether functions can be used in combination with each other or not.

	Application Function Mode			Comparator		Output Functions				
	Piece Counting	Percentage Weighing	Formulation	Target Mode	Checkweighing Mode	Windows Direct Communication Function	Continuous Output	Auto Print	Output Timing Change Function	GLP output function
Application Function Mode	Piece Counting	x	x	○	○	○	△	○	○	○
	Percentage Weighing	x	x	○	○	○	△	○	○	○
	Formulation	x	x	○	○	○	x	x	x	○
Comparator	Target Mode	○	○	○	x	○	○	○	○	○
	Checkweighing Mode	○	○	○	x	○	○	○	○	○
Output Functions	Windows-Direct Communication Function	○	○	○	○	○	x	○	○	○
	Continuous Output	△	△	x	○	○	x	x	x	*
	Auto Print	○	○	x	○	○	x		x	○
	Output Timing Change Function	○	○	x	○	○	x	x		○
	GLP output function	○	○	○	○	○	*	○	○	
See: Page 165 Page 165 Page 165 Page 165 Page 165 Page 165 Page 165 Page 165 Page 165 Page 165 Page 165										












- Can be used in combination
- △ Can be used in combination while the weight value is displayed
- x Cannot be used in combination
- * Weight readings are output, but no other information is output.

13. For Your Information


Menu Map

The menu map represents the organization of the menu options graphically to make it easy to understand.
It is useful for quickly accessing the menu option you want to use.
For details on the organization of the menu settings and the method of operation of the menu, see "3. Menu Settings" (▶ Page 48).

■ Reading the Menu Map

Conventions Used in the Menu Map	Explanation of Operation
	Press  or  to search for the menu option.
	Press  to proceed to the next menu option. Press  to confirm.
	Press  to return to the previous menu option. (Pressing  for around 3 seconds during menu operation returns you to the weighing mode.)
	Refers to a Page in the instruction manual.
	The default settings (settings when the menu is reset)

■ Main Menu (see next page)

Press  in the weighing mode.


STAND	* General weighing mode	▶ Page 83												
POURING	Pouring mode	▶ Page 83												
WINI	◀ WINIU ▶ WIN- ▶ WIN-U	▶ Page 122												
	WindowsDirect communication function													
Z.TRC	* Zero Tracking Function	▶ Page 76												
APLFUNC	Application function mode													
	◀ PCS ▶													
	Piece counting													
	<table> <tr> <td>SAMPLE</td> <td>Item number 1</td> <td>SAMPLE</td> <td>Item number 4</td> </tr> <tr> <td>SAMPLE</td> <td>Item number 2</td> <td>SAMPLE</td> <td>Item number 5</td> </tr> <tr> <td>SAMPLE</td> <td>Item number 3</td> <td></td> <td></td> </tr> </table>	SAMPLE	Item number 1	SAMPLE	Item number 4	SAMPLE	Item number 2	SAMPLE	Item number 5	SAMPLE	Item number 3			▶ Page 95
SAMPLE	Item number 1	SAMPLE	Item number 4											
SAMPLE	Item number 2	SAMPLE	Item number 5											
SAMPLE	Item number 3													
	◀ PERCENT ▶													
	Percentage weighing													
	<table> <tr> <td>SAMPLE</td> <td>100% reference</td> <td>OPTION</td> <td>Specific percentage reference</td> </tr> </table>	SAMPLE	100% reference	OPTION	Specific percentage reference	▶ Page 100								
SAMPLE	100% reference	OPTION	Specific percentage reference											
	FORMULA	Formulation	▶ Page 105											
TOOLS	Other functions													
	◀ TARGET ▶													
	Target mode													
	<table> <tr> <td>TGVAL</td> <td>Target value</td> <td>LMVAL</td> <td>Permissible range</td> </tr> </table>	TGVAL	Target value	LMVAL	Permissible range	▶ Page 111								
TGVAL	Target value	LMVAL	Permissible range											
	◀ CHECKW ▶													
	Checkweighing mode													
	<table> <tr> <td>UPRNG</td> <td>Checkweighing range upper limit</td> <td>LOLIM</td> <td>Pass range lower limit</td> </tr> <tr> <td>HILIM</td> <td>Pass range upper limit</td> <td>UNDRNG</td> <td>Checkweighing range lower limit</td> </tr> </table>	UPRNG	Checkweighing range upper limit	LOLIM	Pass range lower limit	HILIM	Pass range upper limit	UNDRNG	Checkweighing range lower limit	▶ Page 113				
UPRNG	Checkweighing range upper limit	LOLIM	Pass range lower limit											
HILIM	Pass range upper limit	UNDRNG	Checkweighing range lower limit											
	◀ PARAMW ▶													
	Weighing parameters													
	<table> <tr> <td>STBWK *</td> <td>Stability mark</td> <td>FAST *</td> <td>Fast</td> </tr> </table>	STBWK *	Stability mark	FAST *	Fast	▶ Page 86								
STBWK *	Stability mark	FAST *	Fast											
	◀ BAND ▶													
	Stability detection range													
	<table> <tr> <td>0.5g</td> <td>50g *</td> </tr> <tr> <td>1g *</td> <td>100g *</td> </tr> <tr> <td>10g</td> <td>1000g *</td> </tr> </table>	0.5g	50g *	1g *	100g *	10g	1000g *	▶ Page 86						
0.5g	50g *													
1g *	100g *													
10g	1000g *													
SYSTEM	System													
	◀ POINT ▶													
	Decimal point indication													
	<table> <tr> <td>PERIOD *</td> <td>Period</td> </tr> <tr> <td>COMMA</td> <td>Comma</td> </tr> </table>	PERIOD *	Period	COMMA	Comma	▶ Page 44								
PERIOD *	Period													
COMMA	Comma													
	AUTOOFF *	Auto power-off	▶ Page 154											
	BLCLIT *	Backlight (9434 serie only)	▶ Page 156											
	◀ START ▶													
	Start display													
	<table> <tr> <td>AUTO</td> <td>Weighing mode</td> </tr> <tr> <td>SEMAUTO *</td> <td>OFF display</td> </tr> <tr> <td>MANU</td> <td>All segments lit</td> </tr> </table>	AUTO	Weighing mode	SEMAUTO *	OFF display	MANU	All segments lit	▶ Page 155						
AUTO	Weighing mode													
SEMAUTO *	OFF display													
MANU	All segments lit													
	BALID	Scale ID	▶ Page 74											
	PASSWRD	Password	▶ Page 157											
	CONDOU	Menu settings output	▶ Page 55											
	RESET	Menu reset	▶ Page 53											

Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

*: Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

■ Data Output Menu

Press **PRINT** for about 3 seconds in the weighing mode.




*1: Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

13. For Your Information

Menu Map


■ Unit Setting Menu

Press  for about 3 seconds in the weighing mode.




■ Calibration Menu

Press  for about 3 seconds in the weighing mode.



■ Zero / Tare Menu

Press  for about 3 seconds in the weighing mode.



*1: Not applicable to a verified scale as a legal measuring instrument in the EU: Model with EC Type Approval

Soehnle Industrial Solutions GmbH

Gaildorfer Straße 6

71522 Backnang

Phone +49 7191 / 34 53-220

E-Mail info@soehnle-professional.com

All rights reserved.

© Soehnle Industrial Solutions GmbH, Publication, duplication and any form of use, and disclosure to third parties – in parts or in revised form – without the consent of Soehnle Industrial Solutions GmbH is prohibited. Technical changes reserved.

470.066.011 | Version 1 | 09/2016