

COUNTING SCALE

PRODUCT NUMBER 9222

Trade, commerce and industry



- › Large memory for 1,000 reference weights (PLUs) and 12 fast-keys, double assignment possible
- › Unique high resolution and high weighing range: 50kg / 1g; 15kg / 0.5g or 6kg / 0.2g
- › Large convenient stainless steel platform 350 x 240cm
- › Interface RS 232

COUNTING SCALE

PRODUCT NUMBER 9222

Features



The professional counting scale calculates the piece count automatically from a known or queried piece and quantity weight. A one-time entry of the values is sufficient due to extensive memory opportunities. Target values for keeping upper and lower limits can be set manually. An exact counting is possible through the automatic reference optimisation.

Functions

- › Weighing and taring
- › Counting
- › Totalising
- › Memorizing
- › Target values

Characteristics

- › Large memory for 1,000 reference weights (PLUs) and 12 fast-keys, double assignment possible
- › Display switch from piece to weight
- › Bi-directional interface RS232 for printer or EDP connection
- › Backlighted LCD display with 14,5mm high digits for piece count, single and total weight
- › Power supply 230V
- › Integrated accu for approx. 100 hours of operation as standard
- › Weighing platform made of stainless steel
- › Platform size 350 x 240mm
- › Number pad for entry of piece quantity, piece weight or tare values
- › Limit value message (over and unter set value)

Ordering information

Order Numbers	Weighing Range	Divisions	For counting pieces from	Dimensions	Weight
	kg	g	g	mm	kg
9222.01.001	6	0.2	0.2	387 x 365 x 117	5
9222.02.001	15	0.5	0.5	387 x 365 x 117	5
9222.04.001	50	1	1	387 x 365 x 117	5

Your Soehnle Professional dealer:

www.soehnle-professional.com