

DIGITAL INDICATOR

PRODUCT NUMBER 2755

Indicator



- › Weighing ranges: 6 to 1500kg
- › Mains or battery power supply for approx. 350 hrs

DIGITAL INDICATOR

PRODUCT NUMBER 2755



Features

Digital Indicators 2755 are easy to use in applications which require rapid and reliable non-approved weighing operations. They feature weighing, taring, adding and weighing, batching and checking functions, and all with only one key. In addition, there are several options for using the digital indicator in conjunction with a weighing platform, e.g. as checking scale, package scale, floor scale or pallet scale.

Design

- › Max. resolution 30000
- › Weighing range and resolution on request
- › Protection Class IP 54
- › 20mm LCD
- › Membrane keyboard with 2 keys for on/off, zero, tare, and mass unit switchover kg/lb
- › Membrane keyboard with pressure point

Technical Data

- › Housing made of impact resistant plastic, Protection Class IP 54
- › Dimensions: dxwxh 100 x 250 x 50mm
- › Connection from a scale with strain gauge load cells
- › Load cell power source: square-wave voltage at 1000Hz, $3.85V \pm 0.1$
- › Internal resolution at a load cell signal deviation of 1mV/V approx. $n = 16,000$
- › Load cell signal of 1 mV/V
- › Load cell impedance range: 87 to 1000 Ω
- › Load cell connection: 4- or 6-wire
- › Measuring rate approx. 12/s
- › Temperature range: 5°C to -35°C
- › Weighing ranges: 6 to 1500kg
- › Power supply via power adapter, input 230V, 50/60Hz, output 9VDC, approx. 0.45VA
- › Battery power supply for approx. 350 hrs with 4 x 1.5V Mignon cells
- › Auto-Off function (time adjustable)

Scope of delivery

- › Power adapter
- › Wall bracket

Options

- › Charge adapter with rechargeable battery pack for approx. 250 hrs service time

Ordering information

Order Numbers	Description
2755.01.001	Digital indicator, colour RAL 7024 graphite grey
2755.02.001	Digital indicator, colour RAL 7035 light grey

Accessories

Order Numbers	Description
2557.03.001	Charge adapter with rechargeable battery pack

Your Soehnle Professional dealer:

www.soehnle-professional.com