

# DIGITAL INDICATOR

PRODUCT NUMBER 2790

## Indicator



- › Indicator for weighing, taring and counting
- › Approvable
- › Battery power supply for approx. 160 hrs
- › Weighing ranges: 0.1 to 100,000kg

# DIGITAL INDICATOR

PRODUCT NUMBER 2790



## Features

Digital indicator for very high demands. For approved weighing operations – fast and reliable. The indicator can be freely placed next to the scale so that the display is not covered by the weighing product. You have many options of using the indicator together with a weighing platform, e.g. counting scale, checking scale, packet scale, floor scale, pallet scale, wall scale and overhead track scale.

### Technical Data

- › Housing made of anodised aluminium with die-cast parts made of polyamide.
- › Dimensions: l x w x h 306 x 77 x 82.6mm
- › Connect a scale with strain gauge load cells
- › Load cell power voltage: 4V, approx. 67Hz square wave
- › Measuring voltage: 0.2 to 12mV
- › Lowest input signal per calibration value: 0.4µV
- › Load cell impedance range: 87 to 1200 Ω
- › Load cell connection: 4- or 6-wire
- › Temperature range: -10 to +40°C
- › Weighing ranges: 0.1 to 100,000kg
- › Main power via power adapter input 230VAC, 50Hz, output 9VDC, 300mA
- › Battery power supply for approx. 160 hrs with 4 x 1.5V Mignon cells
- › Auto-Off function (time adjustable)

### Design

- › EU Class III
- › Two-range design 2 x 3200e
- › Dust and splash-proof, Protection Class IP 65
- › Backlit 20mm LCD
- › Membrane keyboard with 5 keys for on/off, zero, tare, print and function
- › Function key for optional count, hold, mass unit switchover, BMI and dialysis functions
- › Membrane keyboard with pressure point

### Scope of delivery

- › Power adapter with 2m power cord
- › Desktop and wall bracket

### Options

- › RS 232 serial interface, floating, high protection against interference from external lines
- › Charge adapter with rechargeable battery for approx. 120 hrs service time

## Ordering information

Order Numbers	Description
2790.01.001	Indicator
2790.01.002	Indicator with RS 232 interface

## Accessories

Order Numbers	Description
2512.03.001	Blank nameplate with Declaration of Conformity
2557.04.001	Charge adapter with rechargeable batteries
2550.03.002	Data cable 2m, 9-pole, for PC/IT
5908.04.001	Bench power supply IP 65

Your Soehnle Professional dealer:

[www.soehnle-professional.com](http://www.soehnle-professional.com)