

# WALL SCALE

PRODUCT NUMBER 2821

Trade, commerce and industry



- › Space saving scale with hinged weighing platform
- › Stainless steel version
- › Weighing ranges: 60 or 150kg
- › EU Class III

# WALL SCALE

PRODUCT NUMBER 2821



## Features

Special features of the Wall Scale 2821 are its small space requirement and its special protection against moisture and chemical cleaning agents. The solid compact construction and the overload protection for the load cell ensure long life. The housing and the weighing platform are made of stainless steel 1.4301 and the support structure is galvanised. The scale is fully electronic so it has no moving wear parts and is therefore almost maintenance-free. The compact dimensions and the hinged weighing platform mean that the scale can be used in confined spaces. Attachment to the wall is an

advantage since the scale can be cleaned and there is complete floor clearance. Optionally, an encapsulated load cell is available for use in extremely wet areas.

### Technical data

- > Optional weighing ranges: 60 or 150kg
- > Weighing platform dimensions: l x w 550 x 440mm
- > Approvable to Class III commercial scales
- > Digital indicators: 2 indicator variants are available.

## Digital Indicator 2780 Niro

Housing made of stainless steel with Protection Class IP 65. Gas-permeable membrane to prevent condensation, integrated power supply. One scale connectable, backlit indicator 30mm, membrane keyboard with audible acknowledgement. All basic functions include: zero, tare, optional data interface for printer/IT.

## Digital Indicator 2761 Niro

Housing made of stainless steel with Protection Class IP 65, backlit indicator, 16mm high. Membrane keyboard with audible acknowledgement, RS 232 data interface, basic functions including totalise and batch. Numerical keypad for manual tare input, tare memory, date and time memory, input of organisation data, alphanumeric additional indicator.

## Ordering information

Order Numbers	Design	Weighing Range	Divisions
		kg	g
2821.22.001	Standard	60	20
2821.23.001	Standard	150	50
2821.32.001	Encapsulated load cell	60	20
2821.33.001	Encapsulated load cell	150	50
Order Numbers	Description		
2509.01.001	Mounting hook, stainless steel 1.4301, hook made of aluminium alloy		
5908.01.001	Power adapter IP 65 for 2761		
2503.02.001	Wall bracket Niro for Digital Indicator 2780		

Your Soehnle Professional dealer:

[www.soehnle-professional.com](http://www.soehnle-professional.com)