

PRECISION SCALE

PRODUCT NUMBER 2873.20

Trade, commerce and industry



- > High precision with extremely small divisions
- > Weighing range 4 200g
- > Division 0.01g
- > Internal calibration weight

PRECISION SCALE

PRODUCT NUMBER 2873.20



Features

The Compact Scale 2873.20 features high precision and extremely small divisions. It is specially designed for applications as a precision scale and a reference scale for counting systems.

Design

- > Operated by 5 keys – e.g. power on/off, tare, print
- > Function key for piece count, percentage weigh and check weigh
- > Switchover to other weighing units, e.g. ct, oz, lb etc.
- > Capacity indicator
- > Internal calibration weight
- > Application as a counting scale – smallest piece weight 0.01g
- > Connection as a reference scale to Digital Indicator 3030/3020 via a digital interface
- > Approvable for 0.1g division
- > Units in kg or lb

Technical data

- > Mains power characteristics 230V, 50/60Hz
- > Subtractive taring up to 100% of weighing range
- > Housing made of easy to clean plastic
- > Platform made of stainless steel
- > LC display with 16.5mm digit size
- > Platform size: 175 x 155mm

Scope of delivery

- > Power adapter with 2m power cord

Ordering information

Order Number	Weighing Range	Division		Dimensions	Weight
	g	g (d)	g (e)	mm	kg
2873.20.001	4 200	0.01	0.1	265 x 192 x 87	3.7

Your Soehnle Professional dealer:

www.soehnle-professional.com