

# STEEL WEIGHING PLATFORMS

PRODUCT NUMBERS 2880, 2881, 2882, 2884

Trade, commerce and industry



- › Excellent moisture protection for use in extreme environments
- › Sturdy stainless steel construction
- › Encapsulated load cell with Protection Class IP 67
- › Weighing ranges: 3 to 300kg
- › EU Class III

# STEEL WEIGHING PLATFORMS

PRODUCT NUMBERS 2880, 2881, 2882, 2884



## Features

The stainless steel weighing platforms are extremely sturdy and are designed with excellent moisture protection for use in extreme environments. Two-range weighing range – the range from 0kg is divided into a smaller resolution; the lower range is therefore more precise.

### Indicators

> The weighing platforms can be connected to all Soehnle Professional indicators. Choose the best indicator for your application. The indicators are listed in our catalogue.

### Design





> Sturdy stainless steel construction with strain gauge load cell encapsulated in the stainless steel housing, Protection Class IP 67, designed to withstand extreme environments.

- > Mechanical overload protection to protect the load cell
- > Very fast weight reading
- > Platform made of stainless steel
- > The measuring cable between weighing platform and digital indicator is 2m long.

### Options

- > Chrome steel substructure with 2 steering and 2 drive wheels, 528mm high, bench size l x w 750 x 650mm (Order No. 2502.02.001)
- > Bench stand, stainless steel, for digital indicator (approx. 500mm high) suppliable for Types 2880, 2881, 2882, not available for Type 2884
- > Stand holder made of stainless steel for Digital Indicator 2761 (Order No. 2503.02.002)
- > Stand holder made of stainless steel for Digital Indicator 2780 (Order No. 2503.02.001)

## Ordering information

Type	Order Numbers	Platform Size mm	Weighing Range kg	Divisions
	2880.10.100	275 x 310 x 80	3	1 g
	2880.30.100	275 x 310 x 110	15	up to 6kg = 2g, from 6kg = 5g
	2880.31.100	275 x 310 x 110	30	up to 15kg = 5g, from 15kg = 10g
	2881.29.100	400 x 520 x 130	30	up to 15kg = 5g, from 15kg = 10g
	2881.30.100	400 x 520 x 130	60	up to 30kg = 10g, from 30kg = 20g
	2881.31.100	400 x 520 x 130	150	up to 60kg = 20g, from 60kg = 50g
	2882.39.100	550 x 660 x 170	60	up to 30kg = 10g, from 30kg = 20g
	2882.40.100	550 x 660 x 170	150	up to 60kg = 20g, from 60kg = 50g
	2882.41.100	550 x 660 x 170	300	up to 150kg = 50g, from 150kg = 100g
	2884.40.100	600 x 800 x 125	150	up to 60kg = 20g, from 60kg = 50g
	2884.41.100	600 x 800 x 125	300	up to 150kg = 50g, from 150kg = 100g

Your Soehnle Professional dealer:

[www.soehnle-professional.com](http://www.soehnle-professional.com)