

Weighing beams

the flexible weighing solution for oversized weighing goods or for the self-construction of scales

The weighing beams consist of flat durable tube material, load cells and connection box are protected and accommodated in the structure. We use special load cell feet with rubber dampers for safe load input.

The design height amounts to only 80 mm at a weighing range of 2,000 kg.

If desired, attachment points can be provided for your structures.

When equipped with height adjustment and spirit level, mobile application is possible, rechargeable battery operation for mains-independent weighing is available as an option.

Weighing range, steel or stainless steel material, dimensions, cable lengths and the weighing terminal to be used can be determined individually.

Characteristics

- > Components individually configurable
- > Low own weight
- > Weighing ranges up to 6 tons
- > Plug-in cable connection to the weighing terminal
- > Optionally approvable
- > Wide range of accessory options



Complete system consisting of two steel beams painted and scale terminal 3010



Load cells and connection box protected within the construction